Midea Precision Air Conditioner Technical Manual (Down delivery series)

Midea reserves the right to discontinue, or change specification or designs at any time without notices and without incurring obligations.

Content

1. GENERAL INFORMATION	3
1.1 MEASUREMENTS	
1.2 EXTERNAL APPEARANCE	4
1.3 NOMENCLATURE	5
2. SPECIFICATION & PERFORMANCE	6
2.1Features	6
2.2 REFRIGERANT CIRCUIT	8
2.3 Specifications	10
2.4 DIMENSION (UNIT: MM)	
2.5 SERVICE SPACE	
2.6 WIRING DIAGRAM	
3. INSTALLATION	40
3.1 STORAGE ENVIRONMENT	
3.2 INDOOR INSTALLATION	
3.3 Installing outdoor units	
3.4 CONNECTING REFRIGERANT PIPE	
3.5 VACUUM AND ADD REFRIGERANT	
3.6 WATER PIPE INSTALLATION	50
3.7 ELECTRIC CONNECTION	
3.8 TRIAL RUN	55
4. CONTROL SYSTEM	61
4.1 TABLE OF MAIN CONTROL COMPONENTS AND CONTROL LOAD	
4.2 MAIN CONTROL FUNCTION	
5. OPERATION	

ANNEX I: ALARM TABLE	94
9. ACCESSORIES	93
8. TROUBLE SHOOTING	
7.9 Outdoor fan maintenance	87
7.8 COMPRESSOR MONITORING AND REPLACEMENT	86
7.7 REFRIGERATION SYSTEM	85
7.6 ELECTRICAL HEATING COMPONENTS	85
7.5 HUMIDIFIER MAINTENANCE	83
7.4 INDOOR FAN COMPONENTS MAINTENANCE	83
7.3 FILTER SCREEN MAINTENANCE	82
7.2 Control maintenance	81
7.1 ELECTRICAL MAINTENANCE	81
7. MAINTENANCE	
6.2 The ethernet communication card introduction	
6.1 GROUP CONTROL NETWORK SETTING	
6. NETWORK FUNCTION INTRODUCTION	71
5.5 CLOCK MANAGEMENT	69
5.4 MAINTENANCE MANAGEMENT	68
5.3 SETTING FUNCTION OF USING PARAMETERS	67
5.2 QUERY FUNCTION FOR KEY COMPONENTS OPERATING STATUS	65
5.1 TEMPERATURE/HUMIDITY SET POINT SETTING FUNCTION	

1. General information

1.1 Measurements

Туре		pe Model Dimension (mm, W×H×D)		Outdoor unit (Quantity)	Power Supply
201444	Indoor	MAD020T1N1S1	895×1,971×870	4	380V~,3Ph,50Hz
ZUKVV	Outdoor	MA0331	1,470×988×870		380V~,3Ph,50Hz
	Indoor	MAD025T1N1S1	895×1,971×870	1	380V~,3Ph,50Hz
ZOKVV	Outdoor	MA0431	1,470×988×870		380V~,3Ph,50Hz
201444	Indoor	MAD030T1N1S1	895×1,971×870	1	380V~,3Ph,50Hz
JUKVV	Outdoor	MA0541	1,660×1,290×870		380V~,3Ph,50Hz
	Indoor	MAD035T1N1S1	1,400×1,971×870	1	380V~,3Ph,50Hz
SOKVV	Outdoor	MA0601	1,660×1,290×870		380V~,3Ph,50Hz
40604	Indoor	MAD040T2N1S1	1,790×1,971×870	2	380V~,3Ph,50Hz
40KVV	Outdoor	MA0331	1,470×988×870	2	380V~,3Ph,50Hz
	Indoor	MAD045T1N1S1	1,790×1,971×870	1	380V~,3Ph,50Hz
45670	Outdoor	MA0752	1,980×1,290×870		380V~,3Ph,50Hz
FORM	Indoor	MAD050T2N1S1	1,790×1,971×870	2	380V~,3Ph,50Hz
JUKVV	Outdoor	MA0431	1,470×988×870	2	380V~,3Ph,50Hz
60404	Indoor	MAD060T2N1S1	1,790×1,971×870	2	380V~,3Ph,50Hz
OUKVV	Outdoor	MA0541	1,660×1,290×870	2	380V~,3Ph,50Hz
	Indoor	MAD070T2N1S1	2,685×1,971×870	2	380V~,3Ph,50Hz
70600	Outdoor	MA0601	1,660×1,290×870	2	380V~,3Ph,50Hz
90kM	Indoor	MAD080T2N1S1	2,685×1,971×870	2	380V~,3Ph,50Hz
OUKVV	V Outdoor MA0752 1,980×1,290×870		1,980×1,290×870	۷	380V~,3Ph,50Hz
00k/M	Indoor	MAD090T2N1S1	2,685×1,971×870	2	380V~,3Ph,50Hz
SOKAA	Outdoor	door MA0982 2,480×1,290×87		۷	380V~,3Ph,50Hz

1.2 Exter 1al appearance

Indoo unit-20kW, 25kW, 30 W:



Indoo unit-35kW, 40kW, 45 W, 50kW, 60kW:



Indoo unit-70kW, 80kW, 90 W:



Outdoor unit-Single fan motor:





Outdoor unit-Double fan motors:





Outdoor unit



2. Specification & performance

2.1Features

- V shall be design high efficient evaporato with hydrophilic aluminum fin and inner grooved copper pipe.
- Change the valid evaporator area by electric value to reduce the relative humidity without apparent temperature fluctuation.
- ♦ Reliable electric heater.
- Double wall design, heat-insulated casine reduces the exchanged heat and prevent the condensate from the unit body.
- ♦ Copel ind, special high efficie it compressor.
- Adopt advantage technology of immerse believe humidifier, carel cleanable steam cylinder, and integrated control solution of humidity.
- Accurate microprocessor control technology and key parts: Hi th quality humidity control module, temperature & humidity sensor, frequence converter, pressure sensor.



- ♦ Multiple protections: High and low pressure protection, discharge temperature protection, etc.
- \diamond The running parameter can be displayed in the screen of the control panel.
- 100 pieces of error records can be stored.
- ♦ Three :ypes of password: user password, maintenan :e passwor I, factory password.
- Rotary function, standby fun tion and join-in function can ensure the units keep operating in the whole year.
- ♦ To enhance remote communications and control the precision air conditioners, the Ethernet communication card (optional part) and RS485 card (optional part) can support the communication capabilities as the requirements.



2.2 Refri |erant circuit

Single refrigerant circuit type:





Comp 'essor: R410A, scroll compressor.

Evaporator (Heat exchanger): Copper t use and alu ninum fin type heat exchanger.

Indoo ' Fan: Centrifugal fan

Outdoor Fan: Axial fan

2.3 Specifications

Indoor model		MAD020T1N1S1	
Outdoor model (×Quantity)			MA0331 (×1)
Indoor operating	ambient temperature range	°C	0~40
Outdoor operatir	ng ambient temperature range	°C	-20~45, (-40~45, with low ambient temperature kit)
Altitude		١	\leqslant 1000m (higher than 1000m, derating use)
Indoor Power su	pply	V, Ph, Hz	380V~,3Ph,50Hz
Outdoor Power	supply	V, Ph, Hz	380V~,3Ph,50Hz
Whole unit Rate	d input	W	15,000
Whole unit Rate	d current	А	26.8
	Total capacity	W	20,200
Cooling	Sensible capacity	W	18,580
Cooling	Input	W	7,800
	EER	W/W	2.59
E-heater	Capacity	W	6,000
Humidification	Capacity	kg/h	5
	Model	١	ZP83KCE-TFD-522
	Туре	١	Scroll
	Qty.	١	1
	Brand	١	Copeland
Comprosoor	Capacity	W	20,000
Compressor	Input	W	6,400
	Rated current (RLA)	A	13.6
	Locked rotor Amp (LRA)	A	101
	Thermal protector	١	Internal
	Refrigerant oil	ml	1,774 (POE)
	Model (× quantity)	١	Y(2)100L1-4-2.2KW(YRZ) (×1)
Indoor fan	Brand	١	Huanqiu/Wolong
	Input	W	2,200
	Speed	r/min	1,420
	Number of rows	١	4
	Tube pitch(a)×row pitch(b)	mm	25.4×22
	Fin spacing	mm	1.8
Indoor coil	Fin type	١	Hydrophilic aluminum fin
	Pipe size	mm	Ф9.52
	Pipe type	١	Inner grooved copper pipe
	Coil(W×H)	mm	(726×686)+(726×686)
	Number of circuits	١	9+9
	Туре	\	Axial fan
Outdoor fan	Motor Model (× Quantity)	\	FN071-SDK (×1)
Outdoor fan	Motor Brand	\	Ziehl-Abegg
	Motor Input	W	940

	Speed	r/min	900
	No. of rows	/	3
	Tube pitch(a)×row pitch(b)	mm	25.4×22
	Fin spacing	mm	2.2
Outdoor ooil	Fin type	١	Hydrophilic aluminum fin
Outdoor coll			Ф9.52
	Pipe outside dia. and type	mm	Inner grooved copper pipe
	Coil (W×D)	mm	1,250×914.4
	Number of circuits	١	6
Indoor air flow		m³/h	6,225
Indoor external s	static pressure	Pa	20
Indoor drain pipe	e I.D.	mm	Ф30
Indoor noise lev	el	dB(A)	≪66
Outdoor noise le	evel	dB(A)	≪64
	Туре	١	R410A
Refrigerant	Recharged (After installation)	g	7,500
	Control	١	Thermostatic expansion valve
Maximum refrigeration pipe pressure		MPa	4.4
	Max. pipe length	m	60
Refrigerant	Max. difference in level (O.U. up)	m	20
pipe	Max. difference in level (O.U. down)	m	5
Occurrentian	Indoor power wire	mm ²	3×10.0mm ² (A,B,C) +2×6.0mm ² (N,GND)
Connection	Outdoor power wire	mm ²	4×1.0mm ²
wire	Signal wire	mm ²	4×1.0mm ²
Filter		١	G4
Indoorupit	Net dimension (W×H×D)	mm	895×1,971×870
	Net weight	kg	340
	Net dimension (W×H×D)	mm	1,470×988×690(No include supporting bar)
Outdoor unit	Net weight	kg	105

- 1. The nominal cooling capacity is based on the following conditions. Indoor temperature: 24°CDB, 17°CWB; Outdoor temperature: 35°CDB, pipe length is 10 meters.
- 2. The noise is measured in the semi suppression lab.
- 3. Specifications are subject to change without prior notice for product improvement.

Indoor model		MAD025T1N1S1	
Outdoor model (×Quantity)		MA0431 (×1)	
Indoor operating	ambient temperature range	°C	0~40
Outdoor operation	ng ambient temperature range	°C	-20~45, (-40~45, with low ambient temperature kit)
Altitude		١	\leq 1000m (higher than 1000m, derating use)
Indoor Power su	ipply	V, Ph, Hz	380V~,3Ph,50Hz
Outdoor Power	supply	V, Ph, Hz	380V~,3Ph,50Hz
Whole unit Rate	d input	W	16,500
Whole unit Rate	d current	A	30
	Total capacity	W	26,000
Casling	Sensible capacity	W	23,920
Cooling	Input	W	9,400
	EER	W/W	2.77
E-heater	Capacity	W	6,000
Humidification	Capacity	kg/h	5
	Model	١	ZP103KCE-TFD-522
	Туре	١	Scroll
	Qty.	١	1
	Brand	١	Copeland
Comprossor	Capacity	W	25,200
Compressor	Input	W	7,800
	Rated current (RLA)	А	18.6
	Locked rotor Amp (LRA)	А	111
	Thermal protector	١	Internal
	Refrigerant oil	ml	3,253 (POE)
	Model (× quantity)	١	Y(2)100L2-4-3KW(YRZ) (×1)
Indoor fan	Brand	١	Huanqiu/Wolong
	Input	W	3,000
	Speed	r/min	1,420
	Number of rows	١	4
	Tube pitch(a)×row pitch(b)	mm	25.4×22
	Fin spacing	mm	1.8
Indoor coil	Fin type	١	Hydrophilic aluminum fin
	Pipe size	mm	Ф9.52
	Pipe type	١	Inner grooved copper pipe
	Coil(W×H)	mm	(726×686)+(726×686)
	Number of circuits	١	9+9
	Туре	١	Axial fan
	Motor Model (× Quantity)	١	FN080-ADK (×1)
Outdoor fan	Motor Brand	١	Ziehl-Abegg
	Motor Input	W	1,100
	Speed	r/min	680
Outdoor coil	No. of rows	١	3

	Tube pitch(a)×row pitch(b)	mm	25.4×22
	Fin spacing	mm	2.2
	Fin type	١	Hydrophilic aluminum fin
			Ф9.52
	Pipe outside dia. and type	mm	Inner grooved copper pipe
	Coil (W×D)	mm	1,250×914.4
	Number of circuits	١	6
Indoor air flow		m³/h	7,010
Indoor external s	static pressure	Pa	20
Indoor drain pipe	e I.D.	mm	Ф30
Indoor noise lev	el	dB(A)	≤66
Outdoor noise le	evel	dB(A)	≪64
	Туре	١	R410A
Refrigerant	Recharged (After installation)	g	9,500
	Control	١	Thermostatic expansion valve
Maximum refrige	eration pipe pressure	MPa	4.4
	Max. pipe length	m	60
Refrigerant	Max. difference in level (O.U. up)	m	20
pipe	Max. difference in level (O.U. down)	m	5
	Indoor power wire	mm ²	3×10.0mm ² (A,B,C) +2×6.0mm ² (N,GND)
Connection	Outdoor power wire	mm ²	4×1.0mm ²
wire	Signal wire	mm ²	4×1.0mm ²
Filter		١	G4
Indoorupit	Net dimension (W×H×D)	mm	895×1,971×870
	Net weight	kg	360
Outdoor unit	Net dimension (W×H×D)	mm	1,470×988×690(No include supporting bar)
Outdoor unit	Net weight	kg	105

- 1. The nominal cooling capacity is based on the following conditions. Indoor temperature: 24°CDB, 17°CWB; Outdoor temperature: 35°CDB, pipe length is 10 meters.
- 2. The noise is measured in the semi suppression lab.
- 3. Specifications are subject to change without prior notice for product improvement.

Indoor model		MAD030T1N1S1	
Outdoor model (×Quantity)			MA0541 (×1)
Indoor operating	ambient temperature range	°C	0~40
Outdoor operation	ng ambient temperature range	°C	-20~45, (-40~45, with low ambient temperature kit)
Altitude		١	≤1000m (higher than 1000m, derating use)
Indoor Power su	ipply	V, Ph, Hz	380V~,3Ph,50Hz
Outdoor Power	supply	V, Ph, Hz	380V~,3Ph,50Hz
Whole unit Rate	d input	W	18,500
Whole unit Rate	d current	A	33
	Total capacity	W	30,900
Cooling	Sensible capacity	W	27,810
Cooling	Input	W	11,300
	EER	W/W	2.73
E-heater	Capacity	W	6,000
Humidification	Capacity	kg/h	5
	Model	١	ZP120KCE-TFD-522
	Туре	١	Scroll
	Qty.	١	1
	Brand	١	Copeland
Comprospor	Capacity	W	29,200
Compressor	Input	W	9,200
	Rated current (RLA)	A	20
	Locked rotor Amp (LRA)	A	118
	Thermal protector	١	Internal
	Refrigerant oil	ml	3,253 (POE)
	Model (× quantity)	١	Y2FD100L2-4 (×1)
Indoor for	Brand	١	Huanqiu/Wolong
	Input	W	3,000
	Speed	r/min	1,420
	Number of rows	١	4
	Tube pitch(a)×row pitch(b)	mm	25.4×22
	Fin spacing	mm	1.8
Indoor coil	Fin type	١	Hydrophilic aluminum fin
	Pipe size	mm	Ф9.52
	Pipe type	١	Inner grooved copper pipe
	Coil(W×H)	mm	(726×686)+(726×686)
	Number of circuits	١	9+9
	Туре	١	FN type, AC axial fan
	Motor Model (× Quantity)	١	WZZ800-8 (×1)
Outdoor fan	Motor Brand	١	Ziehl-Abegg
	Motor Input	W	1,100/760
	Speed	r/min	680/530
Outdoor coil	No. of rows	١	3

	Tube pitch(a)×row pitch(b)	mm	25.4×22
	Fin spacing	mm	2.2
	Fin type	١	Hydrophilic aluminum fin
			Ф9.52
	Pipe outside dia. and type	mm	Inner grooved copper pipe
	Coil (W×D)	mm	1447×1219
	Number of circuits	١	12
Indoor air flow		m³/h	8,825
Indoor external s	static pressure	Pa	20
Indoor drain pipe	e I.D.	mm	Ф30
Indoor noise lev	el	dB(A)	67
Outdoor noise le	evel	dB(A)	65
	Туре	١	R410A
Refrigerant	Recharged (After installation)	g	12,000
	Control	١	Thermal expansion valve
Maximum refrige	eration pipe pressure	MPa	4.4
	Max. pipe length	m	60
Refrigerant	Max. difference in level (O.U. up)	m	20
pipe	Max. difference in level (O.U. down)	m	5
	Indoor power wire	mm ²	3×10.0mm ² (A,B,C) +2×6.0mm ² (N,GND)
Connection	Outdoor power wire	mm ²	4×1.0mm ²
wire	Signal wire	mm ²	4×1.0mm ²
Filter		١	G4
Indoorupit	Net dimension (W×H×D)	mm	895×1,971×870
	Net weight	kg	365/432
Outdoor unit	Net dimension (W×H×D)	mm	1,660×1,290×690 (Without supporting bar)
Outdoor unit	Net weight	kg	140/250

- 1. The nominal cooling capacity is based on the following conditions. Indoor temperature: 24°CDB, 17°CWB; Outdoor temperature: 35°CDB, pipe length is 10 meters.
- 2. The noise is measured in the semi suppression lab.
- 3. Specifications are subject to change without prior notice for product improvement.

Indoor model		MAD035T1N1S1	
Outdoor model(×Quantity)			MA0601 (×1)
Indoor operating	ambient temperature range	°C	0~40
Outdoor operatii	ng ambient temperature range	°C	-20~45, (-40~45, with low ambient temperature kit)
Altitude		١	\leqslant 1000m (higher than 1000m, derating use)
Indoor Power su	ipply	V, Ph, Hz	380V~,3Ph,50Hz
Outdoor Power	supply	V, Ph, Hz	380V~,3Ph,50Hz
Whole unit Rate	d input	W	25,000
Whole unit Rate	d current	A	46
	Total capacity	W	34,000
Cooling	Sensible capacity	W	31,280
Cooling	Input	W	12,500
	EER	W/W	2.72
E-heater	Capacity	W	6,000
Humidification	Capacity	kg/h	5
	Model	١	ZP137KCE-TFD-522
	Туре	١	Scroll
	Qty.	١	1
	Brand	١	Copeland
0	Capacity	W	32,600
Compressor	Input	W	10,200
	Rated current (RLA)	А	20.7
	Locked rotor Amp (LRA)	A	118
	Thermal protector	١	Internal
	Refrigerant oil	ml	3,253 (POE)
	Model (× quantity)	١	Y(2)100L2-4-3KW(YRZ) (×1)
Indoor for	Brand	١	Huanqiu/Wolong
indoornan	Input	W	3,000
	Speed	r/min	1,420
	Number of rows	١	4
	Tube pitch(a)×row pitch(b)	mm	25.4×22
	Fin spacing	mm	1.8
Indoor coil	Fin type	١	Hydrophilic aluminum fin
	Pipe size	mm	Ф9.52
	Pipe type	١	Inner grooved copper pipe
	Coil(W×H)	mm	(1,210×660.4)+(1,210×660.4)
	Number of circuits	١	13+13
	Туре	١	Axial fan
	Motor Model (× Quantity)	/	FN080-ADK (×1)
Outdoor fan	Motor Brand	\	Ziehl-Abegg
	Motor Input	W	1,100
	Speed	r/min	680

	No. of rows	١	4
	Tube pitch(a)×row pitch(b)	mm	25.4×22
	Fin spacing	mm	2.2
Outdoor coil	Fin type	\	Hydrophilic aluminum fin
Outdoor coll	Dine outside die, and type		Ф9.52
	Fipe outside dia. and type		Inner grooved copper pipe
	Coil (W×D)	mm	1,448×1,219.2
	Number of circuits	\	12
Indoor air flow		m³/h	10,400
Indoor external s	static pressure	Pa	20
Indoor drain pipe	e I.D.	mm	Ф30
Indoor noise leve	el	dB(A)	≤69
Outdoor noise level		dB(A)	≪64
	Туре	\	R410A
Refrigerant	Recharged (After installation)	g	13,500
	Control	\	Thermal expansion valve
Maximum refrige	ration pipe pressure	MPa	4.4
	Max. pipe length	m	60
Refrigerant	Max. difference in level (O.U. up)	m	20
pipe	Max. difference in level (O.U. down)	m	5
Ogeneration	Indoor power wire	mm ²	3×10.0mm ² (A,B,C) +2×6.0mm ² (N,GND)
Connection	Outdoor power wire	mm ²	4×1.0mm ²
wire	Signal wire	mm ²	4×1.0mm ²
Filter		\	G4
Indoor unit	Net dimension (W×H×D)	mm	1,400×1,971×870
	Net weight	kg	460
Outdoor upit	Net dimension (W×H×D)	mm	1,660×1,290×690(No include supporting bar)
Outdoor unit	Net weight	kg	150

- 1. The nominal cooling capacity is based on the following conditions. Indoor temperature: 24°CDB, 17°CWB; Outdoor temperature: 35°CDB, pipe length is 10 meters.
- 2. The noise is measured in the semi suppression lab.
- 3. Specifications are subject to change without prior notice for product improvement.

Indoor model		MAD040T2N1S1	
Outdoor model(×Quantity)		MA0331 (×2)	
Indoor operating	ambient temperature range	°C	0~40
Outdoor operatii	ng ambient temperature range	°C	-20~45, (-40~45, with low ambient temperature kit)
Altitude		١	\leqslant 1000m (higher than 1000m, derating use)
Indoor Power su	ipply	V, Ph, Hz	380V~,3Ph,50Hz
Outdoor Power	supply	V, Ph, Hz	380V~,3Ph,50Hz
Whole unit Rate	d input	W	32,000
Whole unit Rate	d current	A	60
	Total capacity	W	40,300
Cooling	Sensible capacity	W	38,290
Cooling	Input	W	15,400
	EER	W/W	2.62
E-heater	Capacity	W	9,000
Humidification	Capacity	kg/h	10
	Model	١	ZP83KCE-TFD-522
	Туре	١	Scroll
	Qty.	١	2
	Brand	١	Copeland
	Capacity	W	20,000
Compressor	Input	W	6,400
	Rated current (RLA)	А	13.6
	Locked rotor Amp (LRA)	А	101
	Thermal protector	١	Internal
	Refrigerant oil	ml	1,774 (POE)
	Model (× quantity)	١	Y(2)100L1-4-2.2KW(YRZ) (×2)
Indoor for	Brand	١	Huanqiu/Wolong
indoor ian	Input	W	2,200
	Speed	r/min	1,420
	Number of rows	١	4
	Tube pitch(a)×row pitch(b)	mm	25.4×22
	Fin spacing	mm	1.8
Indoor ooil	Fin type	١	Hydrophilic aluminum fin
Indoor coll	Pipe size	mm	Ф9.52
	Pipe type	١	Inner grooved copper pipe
	Coil(W×H)	mm	(1,590×685.8)+(1,590×685.8)
	Number of circuits	١	18+18
	Туре	١	Axial fan
Outdoor fan	Motor Model (× Quantity)	/	FN071-SDK (×1)
(Single	Motor Brand	/	Ziehl-Abegg
outdoor unit)	Motor Input	W	940
	Speed	r/min	900

	No. of rows	١	3
	Tube pitch(a)×row pitch(b)	mm	25.4×22
	Fin spacing	mm	2.2
	Fin type	/	Hydrophilic aluminum fin
(Single			Ф9.52
	Pipe outside dia. and type	mm	Inner grooved copper pipe
	Coil (W×D)	mm	1,250×914.4
	Number of circuits	/	6
Indoor air flow		m³/h	11,980
Indoor external s	static pressure	Pa	20
Indoor drain pipe	e I.D.	mm	Ф30
Indoor noise leve	el	dB(A)	≪69
Outdoor noise level		dB(A)	≪64
	Туре	\	R410A
Refrigerant	Recharged (After installation)	g	8,500×2
	Control	\	Thermostatic expansion valve
Maximum refrigeration pipe pressure		MPa	4.4
	Max. pipe length	m	60
Refrigerant	Max. difference in level (O.U. up)	m	20
pipe	Max. difference in level (O.U. down)	m	5
Connection	Indoor power wire	mm ²	3×10.0mm ² (A,B,C) +2×6.0mm ² (N,GND)
Connection	Outdoor power wire	mm ²	(4×1.0mm ²)+(4×1.0mm ²)
wire	Signal wire	mm ²	(4×1.0mm ²)+ (4×1.0mm ²)
Filter		\	G4
Indoor unit	Net dimension (W×H×D)	mm	1,790×1,971×870
	Net weight	kg	563
Outdoor unit	Net dimension (W×H×D)	mm	1,470×988×690(No include supporting bar)
(Single)	Net weight	kg	105

- 1. The nominal cooling capacity is based on the following conditions. Indoor temperature: 24°CDB, 17°CWB; Outdoor temperature: 35°CDB, pipe length is 10 meters.
- 2. The noise is measured in the semi suppression lab.
- 3. Specifications are subject to change without prior notice for product improvement.

Indoor model		MAD045T1N1S1	
Outdoor model(×Quantity)			MA0752 (×1)
Indoor operating ambient temperature range		°C	0~40
Outdoor operatii	ng ambient temperature range	°C	-20~45, (-40~45, with low ambient temperature kit)
Altitude		١	\leqslant 1000m (higher than 1000m, derating use)
Indoor Power su	pply	V, Ph, Hz	380V~,3Ph,50Hz
Outdoor Power	supply	V, Ph, Hz	380V~,3Ph,50Hz
Whole unit Rate	d input	W	33,000
Whole unit Rate	d current	A	62
	Total capacity	W	44,900
Cooling	Sensible capacity	W	41,310
Cooling	Input	W	16,900
	EER	W/W	2.66
E-heater	Capacity	W	9,000
Humidification	Capacity	kg/h	10
	Model	١	ZP182KCE-TFD-522
	Туре	١	Scroll
	Qty.	١	1
	Brand	١	Copeland
0	Capacity	W	44,000
Compressor	Input	W	13,500
	Rated current (RLA)	А	29.3
	Locked rotor Amp (LRA)	А	174
	Thermal protector	١	Internal
	Refrigerant oil	ml	3,253 (POE)
	Model (× quantity)	١	Y(2)100L1-4-2.2KW(YRZ) (×2)
Indoor for	Brand	١	Huanqiu/Wolong
Indoornan	Input	W	2,200
	Speed	r/min	1,420
	Number of rows	١	4
	Tube pitch(a)×row pitch(b)	mm	25.4×22
	Fin spacing	mm	1.8
Indoor coil	Fin type	١	Hydrophilic aluminum fin
	Pipe size	mm	Ф9.52
	Pipe type	١	Inner grooved copper pipe
	Coil(W×H)	mm	(1,590×685.8)+(1,590×685.8)
	Number of circuits	١	18+18
	Туре	١	Axial fan
	Motor Model (× Quantity)	/	FN071-SDK (×2)
Outdoor fan	Motor Brand	/	Ziehl-Abegg
	Motor Input	W	940
	Speed	r/min	900

	No. of rows	١	3
	Tube pitch(a)×row pitch(b)	mm	25.4×22
	Fin spacing	mm	2.2
Outdoor coil	Fin type	\	Hydrophilic aluminum fin
Outdoor coll	Pipe outside die, and type		Ф9.52
	Pipe outside dia. and type	IIIII	Inner grooved copper pipe
	Coil (W×D)	mm	1,750×1,219.2
	Number of circuits	\	18
Indoor air flow		m³/h	13,030
Indoor external s	static pressure	Pa	20
Indoor drain pipe	e I.D.	mm	Ф30
Indoor noise leve	el	dB(A)	≤69
Outdoor noise level		dB(A)	≪64
	Туре	\	R410A
Refrigerant	Recharged (After installation)	g	17,000
	Control	\	Thermostatic expansion valve
Maximum refrigeration pipe pressure		MPa	4.4
	Max. pipe length	m	60
Refrigerant	Max. difference in level (O.U. up)	m	20
pipe	Max. difference in level (O.U. down)	m	5
Connection	Indoor power wire	mm ²	3×10.0mm ² (A,B,C) +2×6.0mm ² (N,GND)
Connection	Outdoor power wire	mm ²	4×1.0mm ²
wire	Signal wire	mm ²	4×1.0mm ²
Filter		\	G4
Indoor unit	Net dimension (W×H×D)	mm	1,790×1,971×870
	Net weight	kg	560
Outdoor upit	Net dimension (W×H×D)	mm	1,980×1,290×690(No include supporting bar)
Outdoor unit	Net weight	kg	170

- 1. The nominal cooling capacity is based on the following conditions. Indoor temperature: 24°CDB, 17°CWB; Outdoor temperature: 35°CDB, pipe length is 10 meters.
- 2. The noise is measured in the semi suppression lab.
- 3. Specifications are subject to change without prior notice for product improvement.

Indoor model		MAD050T2N1S1	
Outdoor model(×Quantity)			MA0431 (×2)
Indoor operating ambient temperature range		°C	0~40
Outdoor operatii	ng ambient temperature range	°C	-20~45, (-40~45, with low ambient temperature kit)
Altitude		١	\leqslant 1000m (higher than 1000m, derating use)
Indoor Power su	pply	V, Ph, Hz	380V~,3Ph,50Hz
Outdoor Power	supply	V, Ph, Hz	380V~,3Ph,50Hz
Whole unit Rate	d input	W	36,000
Whole unit Rate	d current	A	65
	Total capacity	W	49,700
Cooling	Sensible capacity	W	45,230
Cooling	Input	W	19,100
	EER	W/W	2.6
E-heater	Capacity	W	9,000
Humidification	Capacity	kg/h	10
	Model	١	ZP103KCE-TFD-522
	Туре	\	Scroll
	Qty.	\	2
	Brand	١	Copeland
	Capacity	W	25,200
Compressor	Input	W	7,800
	Rated current (RLA)	A	18.6
	Locked rotor Amp (LRA)	A	111
	Thermal protector	١	Internal
	Refrigerant oil	ml	3,253 (POE)
	Model (× quantity)	١	Y(2)100L2-4-3KW(YRZ) (×2)
Indoor for	Brand	\	Huanqiu/Wolong
indoor ian	Input	W	3,000
	Speed	r/min	1,420
	Number of rows	\	4
	Tube pitch(a)×row pitch(b)	mm	25.4×22
	Fin spacing	mm	1.8
Indoor coil	Fin type	\	Hydrophilic aluminum fin
	Pipe size	mm	Ф9.52
	Pipe type	\	Inner grooved copper pipe
	Coil(W×H)	mm	(1,590×685.8)+(1,590×685.8)
	Number of circuits	\	18+18
	Туре	١	Axial fan
Outdoor fan	Motor Model (× Quantity)	/	FN080-ADK (×1)
(Single	Motor Brand	\	Ziehl-Abegg
outdoor unit)	Motor Input	W	1,100
	Speed	r/min	680

	No. of rows	١	3
	Tube pitch(a)×row pitch(b)	mm	25.4×22
	Fin spacing	mm	2.2
	Fin type	/	Hydrophilic aluminum fin
(Single			Ф9.52
	Pipe outside dia. and type	mm	Inner grooved copper pipe
	Coil (W×D)	mm	1,250×914.4
	Number of circuits	/	6
Indoor air flow		m ³ /h	14,500
Indoor external s	static pressure	Pa	20
Indoor drain pipe	e I.D.	mm	Ф30
Indoor noise leve	el	dB(A)	≤69
Outdoor noise level		dB(A)	≪64
	Туре	\	R410A
Refrigerant	Recharged (After installation)	g	9,500×2
	Control	\	Thermostatic expansion valve
Maximum refrigeration pipe pressure		MPa	4.4
	Max. pipe length	m	60
Refrigerant	Max. difference in level (O.U. up)	m	20
pipe	Max. difference in level (O.U. down)	m	5
Connection	Indoor power wire	mm ²	3×10.0mm ² (A,B,C) +2×6.0mm ² (N,GND)
Connection	Outdoor power wire	mm ²	(4×1.0mm ²)+ (4×1.0mm ²)
wire	Signal wire	mm ²	(4×1.0mm ²)+ (4×1.0mm ²)
Filter		\	G4
Indoor unit	Net dimension (W×H×D)	mm	1,790×1,971×870
	Net weight	kg	665
Outdoor unit	Net dimension (W×H×D)	mm	1,470×988×690(No include supporting bar)
(Single)	Net weight	kg	105

- 1. The nominal cooling capacity is based on the following conditions. Indoor temperature: 24°CDB, 17°CWB; Outdoor temperature: 35°CDB, pipe length is 10 meters.
- 2. The noise is measured in the semi suppression lab.
- 3. Specifications are subject to change without prior notice for product improvement.

Indoor model		MAD060T2N1S1	
Outdoor model(×Quantity)			MA0541 (×2)
Indoor operating ambient temperature range		°C	0~40
Outdoor operatii	ng ambient temperature range	°C	-20~45, (-40~45, with low ambient temperature kit)
Altitude		١	\leqslant 1000m (higher than 1000m, derating use)
Indoor Power su	pply	V, Ph, Hz	380V~,3Ph,50Hz
Outdoor Power	supply	V, Ph, Hz	380V~,3Ph,50Hz
Whole unit Rate	d input	W	39,000
Whole unit Rate	d current	A	70
	Total capacity	W	59,100
Cooling	Sensible capacity	W	53,190
Cooling	Input	W	22,600
	EER	W/W	2.62
E-heater	Capacity	W	9,000
Humidification	Capacity	kg/h	10
	Model	١	ZP120KCE-TFD-522
	Туре	١	Scroll
	Qty.	١	2
	Brand	١	Copeland
	Capacity	W	29,200
Compressor	Input	W	9,200
	Rated current (RLA)	А	20
	Locked rotor Amp (LRA)	А	118
	Thermal protector	١	Internal
	Refrigerant oil	ml	3,253 (POE)
	Model (× quantity)	١	Y(2)100L2-4-3KW(YRZ) (×2)
Indoor for	Brand	١	Huanqiu/Wolong
indoor ian	Input	W	3,000
	Speed	r/min	1,420
	Number of rows	١	4
	Tube pitch(a)×row pitch(b)	mm	25.4×22
	Fin spacing	mm	1.8
Indoor coil	Fin type	١	Hydrophilic aluminum fin
	Pipe size	mm	Ф9.52
	Pipe type	١	Inner grooved copper pipe
	Coil(W×H)	mm	(1,590×685.8)+(1,590×685.8)
	Number of circuits	١	18+18
	Туре	١	Axial fan
Outdoor fan	Motor Model (× Quantity)	/	FN080-ADK (×1)
(Single	Motor Brand	\	Ziehl-Abegg
outdoor unit)	Motor Input	W	1,100
	Speed	r/min	680

	No. of rows	١	3
	Tube pitch(a)×row pitch(b)	mm	25.4×22
	Fin spacing	mm	2.2
	Fin type	/	Hydrophilic aluminum fin
(Single			Ф9.52
	Pipe outside dia. and type	rnm	Inner grooved copper pipe
	Coil (W×D)	mm	1447×1219
	Number of circuits	/	12
Indoor air flow		m³/h	17,000
Indoor external s	static pressure	Pa	20
Indoor drain pipe	e I.D.	mm	Ф30
Indoor noise leve	el	dB(A)	≤72
Outdoor noise level		dB(A)	≤66
	Туре	/	R410A
Refrigerant	Recharged (After installation)	g	11,500×2
	Control	/	Thermostatic expansion valve
Maximum refrigeration pipe pressure		MPa	4.4
	Max. pipe length	m	60
Refrigerant	Max. difference in level (O.U. up)	m	20
pipe	Max. difference in level (O.U. down)	m	5
Connection	Indoor power wire	mm ²	3×10.0mm ² (A,B,C) +2×6.0mm ² (N,GND)
Connection	Outdoor power wire	mm ²	(4×1.0mm ²)+ (4×1.0mm ²)
wire	Signal wire	mm ²	(4×1.0mm ²)+ (4×1.0mm ²)
Filter		/	G4
Indoor unit	Net dimension (W×H×D)	mm	1,790×1,971×870
	Net weight	kg	680
Outdoor unit	Net dimension (W×H×D)	mm	1,660×1,290×690(No include supporting bar)
(Single)	Net weight	kg	140

- 1. The nominal cooling capacity is based on the following conditions. Indoor temperature: 24°CDB, 17°CWB; Outdoor temperature: 35°CDB, pipe length is 10 meters.
- 2. The noise is measured in the semi suppression lab.
- 3. Specifications are subject to change without prior notice for product improvement.

Indoor model		MAD070T2N1S1	
Outdoor model(×Quantity)		MA0601 (×2)	
Indoor operating ambient temperature range		°C	0~40
Outdoor operatin	ng ambient temperature range	°C	-20~45, (-40~45, with low ambient temperature kit)
Altitude		١	\leqslant 1000m (higher than 1000m, derating use)
Indoor Power su	ipply	V, Ph, Hz	380V~,3Ph,50Hz
Outdoor Power	supply	V, Ph, Hz	380V~,3Ph,50Hz
Whole unit Rate	d input	W	42,000
Whole unit Rate	d current	A	74
	Total capacity	W	71,100
Cooling	Sensible capacity	W	67,550
Cooling	Input	W	26,800
	EER	W/W	2.65
E-heater	Capacity	W	12,000
Humidification	Capacity	kg/h	10
	Model	١	ZP137KCE-TFD-522
	Туре	١	Scroll
	Qty.	١	2
	Brand	١	Copeland
0	Capacity	W	32,600
Compressor	Input	W	10,200
	Rated current (RLA)	A	20.7
	Locked rotor Amp (LRA)	A	118
	Thermal protector	١	Internal
	Refrigerant oil	ml	3,253 (POE)
	Model (× quantity)	١	Y(2)100L1-4-2.2KW(YRZ) (×3)
Indoor for	Brand	١	Huanqiu/Wolong
indoor ian	Input	W	2,200
	Speed	r/min	1,420
	Number of rows	١	4
	Tube pitch(a)×row pitch(b)	mm	25.4×22
	Fin spacing	mm	1.8
Indoor ooil	Fin type	١	Hydrophilic aluminum fin
	Pipe size	mm	Ф9.52
	Pipe type	١	Inner grooved copper pipe
	Coil(W×H)	mm	(2,453×660.4)+(2,453×660.4)
	Number of circuits	١	26+26
	Туре	١	Axial fan
Outdoor fan	Motor Model (× Quantity)	١	FN080-ADK (×1)
(Single	Motor Brand	/	Ziehl-Abegg
outdoor unit)	Motor Input	W	1,100
	Speed	r/min	680

	No. of rows	١	4
	Tube pitch(a)×row pitch(b)	mm	25.4×22
	Fin spacing	mm	2.2
	Fin type	/	Hydrophilic aluminum fin
(Single	Dine outside die, and type		Ф9.52
	Pipe outside dia. and type	11111	Inner grooved copper pipe
	Coil (W×D)	mm	1,448×1,219.2
	Number of circuits	/	12
Indoor air flow		m³/h	20,800
Indoor external s	static pressure	Pa	20
Indoor drain pipe	e I.D.	mm	Ф30
Indoor noise leve	el	dB(A)	≤72
Outdoor noise level		dB(A)	≤66
	Туре	/	R410A
Refrigerant	Recharged (After installation)	g	13,000×2
	Control	\	Thermostatic expansion valve
Maximum refrigeration pipe pressure		MPa	4.4
	Max. pipe length	m	60
Refrigerant	Max. difference in level (O.U. up)	m	20
pipe	Max. difference in level (O.U. down)	m	5
Connection	Indoor power wire	mm ²	3×10.0mm ² (A,B,C) +2×6.0mm ² (N,GND)
Connection	Outdoor power wire	mm ²	(4×1.0mm ²)+ (4×1.0mm ²)
wire	Signal wire	mm ²	(4×1.0mm ²)+ (4×1.0mm ²)
Filter		١	G4
Indoor unit	Net dimension (W×H×D)	mm	2,685×1,971×870
	Net weight	kg	910
Outdoor unit	Net dimension (W×H×D)	mm	1,660×1,290×690(No include supporting bar)
(Single)	Net weight	kg	150

- 1. The nominal cooling capacity is based on the following conditions. Indoor temperature: 24°CDB, 17°CWB; Outdoor temperature: 35°CDB, pipe length is 10 meters.
- 2. The noise is measured in the semi suppression lab.
- 3. Specifications are subject to change without prior notice for product improvement.

Indoor model		MAD080T2N1S1	
Outdoor model(×Quantity)			MA0752 (×2)
Indoor operating ambient temperature range		°C	0~40
Outdoor operatii	ng ambient temperature range	°C	-20~45, (-40~45, with low ambient temperature kit)
Altitude		١	\leqslant 1000m (higher than 1000m, derating use)
Indoor Power su	pply	V, Ph, Hz	380V~,3Ph,50Hz
Outdoor Power	supply	V, Ph, Hz	380V~,3Ph,50Hz
Whole unit Rate	d input	W	48,000
Whole unit Rate	d current	A	91
	Total capacity	W	81,100
Cooling	Sensible capacity	W	73,800
Cooling	Input	W	30,700
	EER	W/W	2.64
E-heater	Capacity	W	12,000
Humidification	Capacity	kg/h	10
	Model	١	ZP154KCE-TFD-522
	Туре	١	Scroll
	Qty.	١	2
	Brand	١	Copeland
	Capacity	W	37,300
Compressor	Input	W	11,600
	Rated current (RLA)	А	25
	Locked rotor Amp (LRA)	А	140
	Thermal protector	١	Internal
	Refrigerant oil	ml	3,253 (POE)
	Model (× quantity)	١	Y(2)100L1-4-2.2KW(YRZ) (×3)
Indoor for	Brand	١	Huanqiu/Wolong
indoor ian	Input	W	2,200
	Speed	r/min	1,420
	Number of rows	١	4
	Tube pitch(a)×row pitch(b)	mm	25.4×22
	Fin spacing	mm	1.8
Indoor coil	Fin type	١	Hydrophilic aluminum fin
	Pipe size	mm	Ф9.52
	Pipe type	١	Inner grooved copper pipe
	Coil(W×H)	mm	(2,453×660.4)+(2,453×660.4)
	Number of circuits	١	26+26
	Туре	١	Axial fan
Outdoor fan	Motor Model (× Quantity)	/	FN071-SDK (×2)
(Single	Motor Brand	\	Ziehl-Abegg
outdoor unit)	Motor Input	W	940
	Speed	r/min	900

	No. of rows	١	3
	Tube pitch(a)×row pitch(b)	mm	25.4×22
	Fin spacing	mm	2.2
	Fin type	/	Hydrophilic aluminum fin
(Single	Dine outside die land type	12122	Ф9.52
	Pipe outside dia. and type	11111	Inner grooved copper pipe
	Coil (W×D)	mm	1,750×1,219.2
	Number of circuits	١	18
Indoor air flow		m³/h	23,300
Indoor external s	static pressure	Pa	20
Indoor drain pipe	e I.D.	mm	Ф30
Indoor noise level		dB(A)	≤72
Outdoor noise level		dB(A)	≪66
	Туре	/	R410A
Refrigerant	Recharged (After installation)	g	17,000×2
	Control	/	Thermostatic expansion valve
Maximum refrigeration pipe pressure		MPa	4.4
	Max. pipe length	m	60
Refrigerant	Max. difference in level (O.U. up)	m	20
pipe	Max. difference in level (O.U. down)	m	5
	Indoor power wire	mm ²	3×10.0mm ² (A,B,C) +2×6.0mm ² (N,GND)
Connection	Outdoor power wire	mm ²	(4×1.0mm ²)+ (4×1.0mm ²)
wire	Signal wire	mm ²	(4×1.0mm ²)+ (4×1.0mm ²)
Filter		١	G4
	Net dimension (W×H×D)	mm	2,685×1,971×870
Indoor unit	Net weight	kg	920
Outdoor unit	Net dimension (W×H×D)	mm	1,980×1,290×690(No include supporting bar)
(Single)	Net weight	kg	170

- 1. The nominal cooling capacity is based on the following conditions. Indoor temperature: 24°CDB, 17°CWB; Outdoor temperature: 35°CDB, pipe length is 10 meters.
- 2. The noise is measured in the semi suppression lab.
- 3. Specifications are subject to change without prior notice for product improvement.

Indoor model		MAD090T2N1S1	
Outdoor model(×Quantity)			MA0982 (×2)
Indoor operating ambient temperature range		°C	0~40
Outdoor operatii	ng ambient temperature range	°C	-20~45, (-40~45, with low ambient temperature kit)
Altitude		١	\leqslant 1000m (higher than 1000m, derating use)
Indoor Power su	pply	V, Ph, Hz	380V~,3Ph,50Hz
Outdoor Power	supply	V, Ph, Hz	380V~,3Ph,50Hz
Whole unit Rate	d input	W	55,000
Whole unit Rate	d current	A	98
	Total capacity	W	90,100
Cooling	Sensible capacity	W	81,090
Cooling	Input	W	34,300
	EER	W/W	2.63
E-heater	Capacity	W	12,000
Humidification	Capacity	kg/h	10
	Model	١	ZP182KCE-TFD-522
	Туре	١	Scroll
	Qty.	١	2
	Brand	١	Copeland
	Capacity	W	44,000
Compressor	Input	W	13,500
	Rated current (RLA)	А	29.3
	Locked rotor Amp (LRA)	А	174
	Thermal protector	١	Internal
	Refrigerant oil	ml	3,253 (POE)
	Model (× quantity)	١	Y(2)100L2-4-3KW(YRZ) (×3)
Indoor for	Brand	١	Huanqiu/Wolong
indoor ian	Input	W	3,000
	Speed	r/min	1,420
	Number of rows	١	4
	Tube pitch(a)×row pitch(b)	mm	25.4×22
	Fin spacing	mm	1.8
Indoor coil	Fin type	١	Hydrophilic aluminum fin
	Pipe size	mm	Ф9.52
	Pipe type	١	Inner grooved copper pipe
	Coil(W×H)	mm	(2,453×660.4)+(2,453×660.4)
	Number of circuits	١	26+26
	Туре	/	Axial fan
Outdoor fan	Motor Model (× Quantity)	/	FN080-ADK (×2)
(Single	Motor Brand	\	Ziehl-Abegg
outdoor unit)	Motor Input	W	1,100
	Speed	r/min	680

	No. of rows	١	3	
Outdoor coil (Single outdoor unit)	Tube pitch(a)×row pitch(b)	mm	25.4×22	
	Fin spacing	mm	2.2	
	Fin type	/	Hydrophilic aluminum fin	
	Pipe outside dia. and type	mm	Ф9.52	
			Inner grooved copper pipe	
	Coil (W×D)	mm	2,250×1,219.2	
	Number of circuits	/	18	
Indoor air flow		m³/h	24,800	
Indoor external s	static pressure	Pa	20	
Indoor drain pipe I.D.		mm	Ф30	
Indoor noise level		dB(A)	≤72	
Outdoor noise le	noise level dB(A) <66		≤66	
Refrigerant	Туре	/	R410A	
	Recharged (After installation)	g	17,000×2	
	Control	/	Thermostatic expansion valve	
Maximum refrige	eration pipe pressure	MPa	4.4	
	Max. pipe length	m	60	
Refrigerant	Max. difference in level (O.U. up)	m	20	
pipe	Max. difference in level (O.U. down)	m 5		
Ogeneration	Indoor power wire	mm ² 3×10.0mm ² (A,B,C) +2×6.0mm ²	3×10.0mm ² (A,B,C) +2×6.0mm ² (N,GND)	
Connection	Outdoor power wire	mm ²	(4×1.0mm ²)+ (4×1.0mm ²)	
	Signal wire	mm ²	(4×1.0mm ²)+ (4×1.0mm ²)	
Filter		/	G4	
Indoor unit	Net dimension (W×H×D)	mm	2,685×1,971×870	
	Net weight	kg	920	
Outdoor unit	Net dimension (W×H×D)	mm	2,480×1,290×690(No include supporting bar)	
(Single)	Net weight	kg	220	

- 1. The nominal cooling capacity is based on the following conditions. Indoor temperature: 24°CDB, 17°CWB; Outdoor temperature: 35°CDB, pipe length is 10 meters.
- 2. The noise is measured in the semi suppression lab.
- 3. Specifications are subject to change without prior notice for product improvement.

2.4 Dime sion (Unit: mm)

170 92 Ó 1971 107 108 84 8484 108 895

870

Indoo 'unit: MAD020T1N1S1, MAD025T1N1S1, M \D030T1N1S1



View of opened doo

Indoo ' unit: MAD035T1N1S1



Indoo unit: MAD040T2N1S1, MAD045T1N1S1, M \D050T2N1S1, MAD060T2N1S1



Indoo 'unit: MAD070T2N1S1, MAD080T2N1S1, M \D090T2N1S1



Outdoor unit: MA0331, MA0431, MA05 41, MA0601



Outdoor unit: MA0752, MA0982



Mod I		Н	W
MA0331	1470	988	690
MA0431			
MA0541	1660	- 1290	
MA0601			
MA0752	1980		
MA0982	2480		
2.5 Servi :e space

Indoo ' unit (Unit: mm)



Outdoor unit with horizontal installation (Unit: mm)



Outdoor unit with vertical installation (Unit: mm)



2.6 Wiring diagram

E-box view of indoor unit



Indoor unit with single system- Controlling connection amplification figure:

Available for MAD020T1N1S1, MAD025T1N1S1, MAD030T1N1S1, and MAD035T1N1S, MAD045T1N1S1



Indoor unit with dual-system- Controlling connection amplification figure:

Available for MAD040T2N1S1, MAD050T2N1S1, MAD060T2N1S1, MAD070T2N1S1, M .D080T2N1S1, and MAD090T2N1S1



Outdoor unit- MA0331, MA0431, MA05 4, MA0601



3. Installation

- ♦ The indoor unit must be installed on the ground of the device room or computer roon. And the outdoor unit is installed on the ground of the outdoors or other rooms.
- ♦ Before the installation, confirm wheth is the installation environment meet the requirements of service, and confirm whether the buildings need to be configured with the construction work of pipeline laying, wiring and ventilation bipe.
- ♦ Installation work must strictly follow the design drawing.
- ♦ The whole system layout diagram:



Notes:

- -----: Pipelines provided by manufacturer
- -----: T is site-laying pipeline (Done by technicians)
- For system normal operation and maintenance convenience, the components are supposed to be used.
 (Done by sit)
- When the equivaltent length of the pipe exceeds 30 neters, then t should be eqquipped with these components. (These optional components need to be purchased by another order).

When the condenser is higher than compressor, install reverse bend on the inlet an I outlet pipes of the condenser, to avoid liquid refrigerant bac flow when the units stops. When installing the reverse bend, it must ensure that the top elbow hipe of the reverse bend higher than the top row copper pipe of condenser.



 \diamond T is installation diagram, when the indoor unit is higher than outdoor unit.



3.1 Stora je environment

Items	Requirements
St rage environment	Indoor, clean.
A ibient humidity	5%~85% RH (No condens ition)
A ibient temperature	Indoor unit: -20°C~54°C; Ou:door unit: -4 1°C~70°C.
St rage time	To al time of transportatio and storage time sho ld not exceed 6
St hage line	months. If exceed 6 month , it need to e-calibrate the capacity.

3.2 Indoor installation

- Take down the packaging case, according to the package diagram to remove the packaging wooden case.
- ♦ Move the back plate, and the unit base was fixe in the bottom wood tray with M8 bolts, remove the bolts with wrench.



- In order to ensure that the environment control s stem in the air conditioning room vorks no mally, it should do the moisture-proof and heat preservation work.
- Computer room should have good th similar insulation and seiled moisture-proof lay ir, the misture-proof layer of ceiling and wall must use polyethylene film materials. The painting of concrete wall and ground must be moisture-proof.
- Outdoor air enter into the room may increase the system cooling, heating, humidifying and dehumidifyting load, so it is necessary to minimize outdoor air enter into the room. Hutdoor air inhaled quantity should remain below 5% of whole indoor air circulation amount, all the doors and windows should be fully enclosed type, and aperture are as small as possible.
- Because the air conditioner will produce the condensate and water leakage may cause the damage of other precision equipments nearby, there is not the precision equipments near the indoor unit, and the installation scene of air conditioner must be provided the drainage pipelines.
- ✤ To ensure the normal ope ation of indoor unit, it should choo se capacious space as the indoor unit installation site.
- ♦ Do not install the indoor unit in the narrow space, or it would block the air flow, and shorten the refrigeration cycle, and then leads to a short circuit of returning air and air noise.

- ♦ Do not fix the indoor unit in the sunken place or at the end of the long and narrow room.
- Do not make several indoor units to be huddled together, to ivoid crossing the air and producing the unbalanced competition operation.
- ♦ Do not install other equip nents on its upper part, convenient for its normal maintenance.
- ♦ According to the bottom installation size of the in loor unit, the installation base should be installed.
- \diamond PI ice rubber damping mats on the to of the installation base and steel plate botto i.
- ♦ Determine the installation position, and according to the site condition and user's requierments to install the installation bas + at the selected position.
- ♦ Use bolts, cushion, flat m it and nuts o fix the air conditioner on the base.
- All outside plates of the u it should not allow bearing weight, it must be considered when choosing installation angles and fixed holes.
- ♦ Si Igle-door unit installation basing si :e: (Unit: m n)



♦ Dual-door unit installation basing size: (Unit: mm)



 \diamond Three-door unit installatio 1 basing size: (Unit: m 1)



Item		Specification (m n)	Remark
Steel plate		100×100×(5~6.5	
Angle iron (Steel	channel)	40×4)×3 (50×37×4.5)	
Anti-shoc	Тор	Thickness: 3~5	Rubbe materical can choose isoprene rubber, different bulyl
rubber pa I	Bottom	Thi kness: 10~1 !	rubber or rubber gasket with the same similar properties.
Fixing hole for exp	pansion bolt		Install is user requirements.
Ц		200	This is only for referince, it should according to the actual
		300	needs of users.

Notes:

The installation base should be strong to s pport the in loor unit.

- To prevent deformation and damage during tran portation, it was added fasteners or vibration reduction materials on the key places when the unit left fact ry. Remove the transportation fasteners and vibration reduction materials before installing and debugging the unit.
- First dismantled three L shape fixed metal plates, and install the bolts and gaskets with the bolts fastening torque: 12±1N. n.



3.3 Installing outdoor units

- ♦ After the unit arrives, check whether it is damag d during the shipment.
- ☆ To ensure the heat dispersion of the unit, intall the outdoor unit at the will-ventilated outdoor, avoid places with dust, s ow, etc. It will block the condensed coils.
- It is suggested that user should horizontal intall the unit if the installation conditions allow, which h slp to low down the noise.
- ♦ In stall the unit far away from the resi lential area.
- ♦ When it is installed at the top of the building, pay attention to the water proof layer and obey the related local rules.
- ♦ T is installation direction please refers to the installation arrow label on the outdoor unit.
- ♦ Outdoor unit has two methods of installation: horizontal inst Illation and vertical inst Illation.





In side the package of outdoor unit, there are fou supporting bars which are fixed in horizontal in sallation.

Vertical (Top view):



For horizontal installation:

In stall the outdoor unit supporting ba to ghe unit first, use 6 screws to fix the supporting bar
 (I6×23 Screws in accessories pack ige), totally 4 bars.



				(Unit: mm)
Model	L1	H1	D1	D2
MA0331	1110	764		
MA0431	1112	704		
MA0541	1210		40	62
MA0601	1310	1066	49	03
MA0752	1604	1000		
MA0982	2105			



 \diamond It is suggested that use $|6\times 20$ expansion bolt for fixing the mounting base.

For vertical installation



 \diamond It is suggested that use M6×20 expansion bolt for fixing the nounting bise.

3.4 Connecting refrigerant pipe

- ♦ F in ensure safety, before welding the pipelines and welding spots, must completely discharge the nitrogen in the air conditioner system, which can release the system pressure.
- D > the heat insulation for the copper pipes. When the copper pipes go through the walls or other o istacles, vibration isolating measurements as shock pad should be done for avoiding the copper pipes direct contact with the vall, meanwhile pay attention to keep dust, aq ieous vapor, p inticles and so on away from the copper pipes.
- ♦ It needs to apply high qu ility silver fiber for welding the pipeline connectors. During the welding

process, it needs to char je nitrogen into the pip line for protection.

- \diamond Make sure the right connecting pipe size.
- \diamond Make sure the outdoor u it installation height of unit pipeline installation.
- ♦ Fill refrigerant and add refrigerant and add refrigerant oil of unit pipeline installation.
- ☆ T is pipeline pressure drops, compressor oil return, noise reduction and vibration reduction should be considered during the design and construction processes.
- If one way equivalent length is longer than 30m, or the vertical height definence of indoor and outdoor units is higher than the numperical showed in following table, then it needs to confirm wrether need to add the extended components before installation.

Relative position	Value
Outdoor unit installed level is higher than indoor unit	Max. 20m
Outdoor unit installed level is lower than in loor unit	Max5m

- ♦ In stall grease traps (oil loop) every 7.5 meters of the all vertical height tubes.
- ♦ T is suggested pipeline sizes in the following table are equivalent length, the frictio i losses of el pow and the valve have counted. The installer will confirm whether it is appropriate according to the site conditions.

Outdoor diameter of	E	quiv lent le	ngth (Meter)
liquid pipe (Inch)	90° 3end	45° Bend	T-s ape three-way
3/8	0.21).1	0.76
1/2	0.24	0.12	0.76
5/8	0.27	0.15	0.76
3/4	0.3	0.18	0.76
7/8	0.44	0.24	1.1
1-1/8	0.56	1.3	1.4

- When the unit leave the factory, it will has a small amount of refrigerant in the indoor unit, the outdoor unit is filled with hitrogen gate to stay the pressure, and must be put off all these materials before connect the indoor unit and out loor unit at site.
- When welding the copper pipe with the indoor and outdoor unit, pack the wet clothon the ball valve before welding. During welding, pay attention to do not burn the labels near the base panel and side panel of unit.



- ♦ Do not open the system pipeline more than 15 minutes, or it will lead to freeze the cooling oil and influence the usage lifespan of the key parts in the system and the system operation stability.
- The horizontal part of the gas pipe should be sloped down part after led out from the compressor, its gradient at least should be 1:200 (every 1m should drop 5mm). But if the air exhaust pipe is located at the place of cooling equipments (including under the block up floor) then it should be insulated.
- ♦ Considering the diameter will cause the system pressure drop loss, the copper pipes diameters connecting between indoor and oudoor units.

Indoor unit model	Length	10m	20m	30m	40m	50m	60m
	Gas pipe	22mm	22mm	22mm	22mm	22mm	22mm
MADUZUTINIST	Liquid pipe	13mm	13mm	13mm	13mm	16mm	16mm
	Gas pipe	22mm	22mm	22mm	22mm	25mm	25mm
MAD0251111151	Liquid pipe	13mm	13mm	16mm	16mm	16mm	16mm
	Gas pipe	22mm	22mm	22mm	22mm	25mm	25mm
MADUSUTINTST	Liquid pipe	13mm	16mm	16mm	16mm	16mm	16mm
	Gas pipe	22mm	22mm	22mm	22mm	25mm	25mm
MAD0351111151	Liquid pipe	13mm	16mm	16mm	16mm	16mm	16mm
	Gas pipe	22mm	22mm	22mm	22mm	22mm	22mm
MAD04012N131	Liquid pipe	13mm	13mm	13mm	13mm	13mm	16mm
	Gas pipe	22mm	22mm	25mm	25mm	28mm	28mm
WAD0451111151	Liquid pipe	16mm	16mm	16mm	16mm	19mm	19mm
	Gas pipe	22mm	22mm	22mm	22mm	25mm	25mm
MAD05012N151	Liquid pipe	13mm	13mm	16mm	16mm	16mm	16mm
	Gas pipe	22mm	22mm	22mm	22mm	25mm	25mm
MAD00012N131	Liquid pipe	13mm	16mm	16mm	16mm	16mm	16mm
	Gas pipe	22mm	22mm	22mm	22mm	25mm	25mm
MADU/UTZNTST	Liquid pipe	13mm	16mm	16mm	16mm	16mm	16mm
	Gas pipe	22mm	22mm	25mm	25mm	28mm	28mm
IVIADU6012IN151	Liquid pipe	16mm	16mm	16mm	16mm	19mm	19mm
	Gas pipe	22mm	22mm	25mm	25mm	28mm	28mm
IVIADU9012N151	Liquid pipe	16mm	16mm	16mm	16mm	19mm	19mm

Notes:

If the pipe length is more than 60m, please consult the manufacturer.

- When the pipe equivalent length is more than 30m, then it needs to install the extended components. During the extended components installation, to prevent pipelines open, it suggested that install the extended the electromagnetic valve body components on the outside of the liquid pipe ball valve, or int the outside or the bottom of the equiment.
- So in the electromagnetic valve installation operation process, it do not need to cut the indoor pipeline, and after the whole system installation, then open the ball valve for pressurizing and vacuum operation, to avoid moisture absorption of the compressor frozen oil, and ensure that

the operation of the compressor and its lifespan. Trash and foreign matters may come into the pibe in the process of pipe intallation. Be sure to blow them off with niltrogen before connecting the pipe to the outdoor units.

♦ T is electromagnetic valve wire connection as the following figure:





3.5 Vacu Im and add refrigerant

- After finished piping connection between the ind or and outdoor unit, open all ball valves, and then filled with 30kgf/cm² nitrogen from the outd or unit cover connector, and then pressurizing for 24 hours.
- Under the pipeline press irizing was no problem, use vacuuin pump to vacuum refrigeration system loop to below 20 'a, and kee) for 2 hour ;, if the pressure is no picks up, the liquid sight glasses in indoor unit will indicate to be green.
- ♦ After the vacuum inspection, the refrigeration system should static filling quickly by becified a nount liquid refrigerant and adds salitable amount refrigerant oil.
- If the connecting pipe length of indoor unit and outdoor unit is within 10m, the filling refrigerant is
 1 kg.
- When the connecting pip i length is nore than 1)m, then it needs to add refrigerant into the system for the system normal operation. The calculation for the added quantity of refrigerant is as the folling formula:

A Iding amount of refrigera it (kg) =

C rresponding unit Length additional refrigerant amount (kg/m) **×Total length of extend liq id pipe** (m) The corresponding unit length additional refrigerant amount for different liquid pipe diameters:

Liquid pipe outer diam :ter (mm)	Refrigerant adding a nount per meter (kg/m)
12.7	0.11
16	0.17
19	0.26
22	0.36
25	0.52
28.6	0.68

Total length of the extend liquid pipe (m) = Total length of liquid pipe (n)-10m

Add refrigerant will cause the system refrigerant oil dilution, which affect the refrigerant oil lu prication and cooling effect, therefore, it needs to add refrigerant oil. Additional formula is as follow:

A lded refrigerant oil amount (ml) =

R frigerants additional amount (kg) × 22.6

3.6 Water pipe installation

- C indensed water drainage pipes of humidifier and evaporator are gathered by the T adapter and drained out. The inner diameter of the tube is 30mm, if more than 3 sets units share a root pipe, then the tube inner diameter should be minimum 40mm.
- ☆ T le drainage pipe should be connected with a U shape joint pipe, which te nperature of continuous thermal resistance is higher than 100°C. The U shape must be installed vertically.
- T is water leakage detec or should be installed under the joint of drainage pipe and root, which wirings is connected with terminal 01 and 47. If the place under the pipe joint is flat, the detector can directly be installed there. If the place is un even, the detector should be installed the place where is easy to collect the water.





N ites:

B ≥ P/10+20 (Unit: mm) A ≥ B/2 (Unit: mm) P: Air outlet static pressure (Unit: Pa)

↔ H imidifier also needs to connect with an inlet vater pipe. Install a sid ∋-pass stop valve and a filter device on the wate inlet pipe, for mainte ance convenience. The filter mesh number of filters should not less than 40.

Figite index of fordinger? Jater quality			Limit	valve
Finde index of ordinary fater quanty			Min.	Max.
P I value	PH		7	8.5
R lative electric conducti /ity at 20°C	SR,20°;	µs/ ;m	3)0	1250
Total hardness	TH	mg/I CaCO ₃	=	400
Temporary hardness		mg/I CaCO ₃	=	300
Total non-soluble solid	CR	mg/l	(*)	(*)
S ilid waste at 180°C	R180	mg/l	(*)	(*)
Iron + Manganese		mg/l Fe+Mn	=	0.2
C ılorine		ppm Cl	=	30
Silica		mg/l 3iO ₂	=	20
C ıloride ion		mg/l Cl⁻	=	0.2
C alcium sulfate		mg/I CaSO ₄	=	100

\diamond R squirements for the water quality in let to the humidifier:

P J tube can be directly connected with outer water pipe. It must seal connect in to prevent leakage.

- T ie normal working pressure rang i of main pipe is 100kPa to 800kPa. It should install a pressure reduced device on the place pressure more than 800kPa. If the main pip is pressure is below 100kPa, it should set water collecting sump and water pump system. The water inlet pipes of main pipeline must in accordance with the loc il regulations.
- T is water inlet pipe conjecting accessories as following shows. It has equipped with the unit, the connectors of the water pipe are only for reference to choose.



3.7 Electric connection

- All the power wires, controlling wires and the grounding connection should observe the national and local regulations and electrical rilles.
- ♦ T ie main power supply r equirement : 380V AC, 50Hz, 3Ph.
- Before connect the electric circuit, use the voltmeter to test the input power voltage, and confirm the power supply has been closed.
- \diamond Base panel has three cutting holes to passby the wirings.



If it is difficult for piping a id wiring from the base panel, then it can choose from the side panel fo connection. Knock do vn the plate of side panel cutting hole, (2 cutti ig holes both on right and left sides) according to the actual need to choose import and export ports, but it must ensure that any two of the pipeline, power wire and signal wire to outlet from the different hole.



- ♦ Fix the spare wirings on the electric able fastening clamp.
- ♦ Wiring refers to indoor unit power wiring diagram, as following picture.





Dual-system :ype

♦ Wiring refers to outdoor unit wiring diagram, as following picture,



 \diamond Field wiring,



Dual-system type\

- ♦ U se protection pipe or shielding wire for the outdoor parts of the connecting wires of indoor unit and condenser.
- ♦ D > not contact the cables with high t merature objects (Such as non-heat insulated copper pipes, compressor, etc.) for protect t le insulation layer.

3.8 Trial run

♦ In roduction of LCD man al operator functions



F is all th buttons, when it is displaying or modifying the operation para lieters, sho is a green lanp to mean a paragraph is selected silicone rubber button which has three different color lanps.

Discriptions of display lamp:

O 1/Off key: Green color, light up means that unit is on. Flash means that close the unit by switch in out or monitor.

Alarm key: Red colour, Light up means one or or ore alarms.

OK key: Yellow colour, light up means that device normally is powered.

B uttons descriptions of LCD man al operato .

Menu

Menu:

Back to Menu (*M0*) under any displa ⁷ situation (Except checking factory parameters situation) will display unit status, probe reading and operating mode, under factory interface, pressing this button can go back.



Maintenance:

Shift to the first page of the maintenance interface (A0), usu III the maintenance parameters are use for check the operating status, p obe readin j, maintenance, calibration reading and manual o reratiom of the device.



Print:

Q lick display the pLAN address of c lirrent control plate.



Status (Input/Output):

Shift to the first page of input/output interface (I0), input/output status of input and output p rameters display control plate.



S lift to the first page of time program (*K0*). Time parameter is used to display and set the σ erating parameter of clock plate a d activate time zone.



S lift to the first page of set point pro gram (S1).



Program:

S lift to the first page of user interface (**P0**). User interface is used to change the unit operating mode.



Query:

When the unit is under group control state, can ress this button to shift different unit display n ges

p ges	
on/off	
	on/off:

On/off the unit.



alarm:

Display the alarm, elimin ite the alarm sound, and eliminate the current alarm.



If the cursor moves to the upper left corner, click this button can page up in the same programsectiom; If the cursor moves to a certain parameter position, click this button to increase the parameter value.



Down:

If the cursor moves to the upper left corner, click this button the same program section; If the cursor moves to a certain parameter position, click this button to decrease the portrameter value.



enter:

Generally move the curs or from the opper left to the setting area, after setting para neters then press this button to confirm and make the cursor move to the next setting parameter.

♦ Before trial run, the mechanical part and eletrical part shoud be checked first.

- \diamond T is mechanical part:
 - Make sure remove t le protective materials for the transportation. Check the fastening situation of motor wheel and fan wheel, and also check the parallelism of moto⁻ wheel and fan whell and the tension of the pelt.
 - ✓ Make sure the refrig rant and lu prication oil have been illed strictly.
 - ✓ Make sure the water drainage pipelines of humidification system have been connected reliably and check the leakage.
 - ✓ Make sure the heating belt of compressor has been pre-heated over 12 hours.
 - ✓ Make sure the room temperature is over 20°C and has some thermal load. If n t, it should be used other heating devices or operated the electrical heating of the unit to pre-heat the room environment, and make sure there are rated capacity thermal load for trial run.
 - ✓ Under the situation i i winter, it n eds to man-made shadow parts of condense I area and limit the condensed ir volume to increase the condensed pressure.
- ♦ Electrical part:
 - ✓ Make sure the main power input woltage is in the range of -10%~15% voltage. Power disconnecting switch of the outd or unit has been closed.
 - ✓ Make sure all the electrical or controlling wires are correctly connected, and fasten all the connectors of electrical and controlling connections.
 - ✓ When terminal number 22 and 5 are connected well, the outdoor fan can not receive the control signal from indoor unit, and it can not operate. It will cause the system stop as high pressure.
 - ✓ Separated arrange t ie power cable and the low voltage controlling cable.
 - ✓ It has ensured that t is phase sequences of the three-phase components are the same when leaving the factory. It only needs to make sure the phase sequence is colrect. If fault, change any two wires between A, B,C of the main power supply.
- ♦ T is system manual dete stion function:

Under standby state, the controller provides the functions of manual on and off at site to detect the status of the system functional components, detailed operation steps as following:

- ✓ Switch on the main power supply, at that time, the unit is under standby state, and the indication lamp on the upper rig at corner of the main controller will display green, the manual operator dis a lay interface will display the unit was turned off.
- Press the Maintena ice key on the manual operator, and enter to the maintenance interface, and keep pressing the Down button to shift the page to A5 interface, and then it needs to type in maintenance password.

Password	A5
Maintenance	0000

Notes:

The maintenance password can be got from manufacture.

✓ After confirm the password, kee → pressing the **Down** button to enter the following interface,

and use the **enter** key to move the cursor position, and use the **Do n** button to carry out the manual on/off setting of the critical components, and then press the **enter** key for confirmation.

Manual ProcedureAcDout 04Heater1OffDout 05Heater2OffDout 06DEHUMI ValveOff	Manual ProcedureAbDout 01FANOffDout 02COMP1OffDout 03COMP2
Manual Procedure Ad Dout 07 Off Dout 08 ALARM Off	Manual ProcedureAeDout090ffDout100ff
Manual ProcedureAoDout 11HUMI POWEROffDout 12FILLOffDout 13DRAINOff	Manual ProcedureAfAout01AUT00.0VAout02AUT00.0V
Manual ProcedureAgAout03AUT00.0VAout04AUT00.0V	New maintenance Am password: 0000

- ♦ Manual operator display and operation methods
 - ✓ After the unit is on, enter to the main interfa and it will display some current masic parameters setting, include cloc c message, curren ambient temperature and humidity value and the unit status. Tress the Set button to set the temmerature and humidity, and through the enter key to move the curso r and use the Up and Down keys to change the parameter and press enter key for confirm mation.

Set point:	S1
Temperature.	21.5°C
Humidityd.	50.0%

✓ Press the Menu button to go ba k to MO page, and press Down key to query the current operating mode, or adjust the setting parameters, after adjusted the setting parameters and press enter button for confirmation.

Work mode	M1
Cooling	
Heating	
Humidification	
Dehumidification	

✓ Compressor checking: Press the Set key, the setting temperature to be room temperature minus 5°C, the relative humidity to be the same as the room temperature, and press enter to observe the compressor whether operates or reverses. (The compressor reverse then it will has abnormal voice.)

Note:

The compressor cannot be reversed over 30 seconds, and it should be judged immediately and cut off the power.

Back to *M0* page, and press **Status** to check the rising pressure of the compressor is normal or not, and at the same time, the outdoor fan should be high speed operating, and the stable pressure of the compressor should about 30bar.

- Cooling state detection: Press the Menu and press the Down button to check the current mode is cooling or not.
- Dehumidification function detection: Press the Set to change the temperature as the same as the room temperature, and relative humidity set to the room temperature minus 5%RH. Press enter and the compressor will be normally operated, and then press the Menu, press Down key to check the current mode is dehumidification or not.
- Humidification function detection: Operate the humidifier switch, press the Set to change the temperature as the same as the room temperature, and the relative humidity set to be the room temperature plus 5%RH, then press enter to check the compressor stops or not and the humidifier starts to inlet water or not. Press the Status, find the *li* page, and check the current flow of the humidifier whether increased gradually, and wait the action of the humidification tank change from *Water inletting* to be *Evaporating*. Press Manual drainage switch to drain off the water.
- ✓ The first grade heater detection: Operate two electrical heater switchs, press Set to set the temperature to be room temperature plus 2°C, and the humidity stays the same as the indoor humidity. Press enter to check whether stop humidifying and whether operate the first grade electrical heating pipe, and then press Menu, Down key to check whether display heating mode.
- The second grade heater detection: Press Set to set the temperature to be room temperature plus 4°C, and the humidity stays the same as the indoor humidity. Press enter to check whether operate the second grade electrical heating pipe, and then press Menu, Down key to check whether display heating mode.
- Dehumidification heating mode: Press the Set button to change the relative humidity to be indoor humidity minus 5%, press enter to check the compressor whether operates, and then press Menu, Down to check whether display dehumidification heating mode.
- Humidification heating status detection: Press Set to change the relative humidity to be indoor humidity minus 5%, press OK to check the compressor whether stops and the humidifier starts to inlet water and starts humidifying or not, at that time the humidification tank will be getting hot, and then press Menu, Down to check whether display humidification heating mode. Press Manual drainage switch to drain off the water.
- Cooling humidification status detection: Press Set key to change the temperature to be indoor temperature minus 5%, press enter, and operate the unit after the unit stops one minute, to check whether continue humidifying or not; and press Menu, Down to check whether display cooling humidification mode.

- Safe operation of refrigerant system detection: Operate the compressor, and after the unit is stable operated then check whether there are bubbles in the liquid sight glass. Adjust the thermal expansion valve to the suction degree of overheating be about 5°C~8°C, and each adjustment should not over 1/2 circle and at least observe over 15 minutes every time. Observe the compressor gas suction pipeline, make sure the pipeline and the compressor cover have no condensed water and eliminate the potential liquid slugging danger. Under the status of 24°C 50%RH air return and 29~30bar condensing pressure, the compressor gas suction pipelate.
- ♦ Steps after trial run
 - \checkmark Reset the unit to default status.
 - Check and make sure the temperature and humidity setting value and control precision are reasonable.
 - \checkmark Check and make sure other functions are reasonable.

4. Control system

4.1 Table of main control components and control load

No.	Name	quantity
1	Controller	1
2	Operation displ ayer	1
3	Te perature & humidity sensor	1
4	OE / humidifier connector component	1
5	Fan speed regulating inverter	1
6	Pressure transmitter	1
7	Fan pressure differernce s vitch	1
8	Heater 1	1
9	Heater 2	1
10	Compressor	1
11	Inner fan	1
12	Out er fan	1

♦ Schematic diagram of the main controller terminals



Code	Name	
J10	Standard us :r port, non lect to manual operator	
N01	Indoor fan	
N02	Compressor 1	
N03	Compressor 2	
N04	E-heater 1	
N05	E-heater 2	
N06	Dehumidification solenoid valve	
N08	Alarm output	
N011	Humidifier	
N012	Humidifier water inlet valve	
N013	Humidifier water outlet valve	
Y1	Indoor fan regulation	
Y3	Outdoor fan regulation 1	
Y4	Outdoor fan regulation 2	

ID1	Compressor 1 high pres sure
ID2	Compressor 2 high pres sure
ID3	E-heater 1 overload
ID4	E-heater 2 overload
ID5	Phase sequence protection
ID6	Indoor fan overload
ID7	Air flow switch
ID8	Remote control
ID9	Compressor 1 low pressure
ID10	Compressor 2 low pressure
ID11	Humidifier water level al arm
ID12	Sparkles alarm
ID13	Filter screen blocking
ID14	Water leakage alarm
ID13H	To 220V signal
ID14H	To 220V signal
B1	Indoor humidity
B2	Air discharging pressure 1
B3	Air discharging pressure 2
B4	Outdoor tem perature
B5	Indoor temperature
B6	Air outlet te perature
B7	Electric conductivity con rector
B8	Humidification current
TX-/TX+	RS485 Concatenating connector

♦ O EM humidifier connector components





♦ In Joor schematic diagram



Manual operator

♦ Outdoor fan frequency conversion



Butto 1	Mame	Functions
		1, For shifting to system monitoring status.
MON/ESC Monitoring/ESC	2, Back to the previous nenu.	
		3, Clear the alarm when the inverter was under alarm state.
		1, Enter to the menu.
ENTER	Data/Comm	2, Confirm to amend the data.
		1, Under q lick monitorin; mode, shift to the monitored parameter.
>> Shifting	2, Under d ita amending, shift to amend position.	
	3, When a nend the function code, increase as 10 units. (Only valid for P0	
		function)
	Up	Add the function code or data.

	Direction/Jog	Accord to t ie function code to carry out one of the f illowing functions:	
DIR/JOG Direction/Jog		1, Change the operating direction of inverter.	
		2, Operate the inverter thunder the jog status, loosh the key then jog will	
	stop.		
RUN	Run	Under keypad control st te, this button will operate the inverter.	
▼	Down	Reduce function code or data.	
STOP/RE ;ET	Stop/Reset	1, When the inverter under normal operation, stop the inverter op ration.	
		2, When the inverter under error statu , reset the error.	
		3, According to the function code to carry out emergency stop functiom.	
		(Equal to outer error input.)	

Lamp name	Status	Instruction ;	
On The inve ter is under operating or jog status. RUN Flash The inve ter is slowing down to stop. Off The inve ter is under stop status.		The inve ter is under operating or jog status.	
		The inve ter is slowing down to stop.	
		The inve ter is under stop status.	
	On	The inve ter is under i version status.	
DIR Flash The inve ter is under corotation-inversion transition. Off The inve ter is under corotation status.		The inve ter is under corotation-inversion transition.	
		The inve ter is under corotation status.	
On Operation panel control status. (Local control)		Operation panel control status. (Local control)	
Off		Terminals or serial communication ort control status.	
On		Slightly error alarm. (ver-current, over pressure.)	
	Off	The inve ter output cu rent and bus voltage normally.	

4.2 Main control function

- ♦ Adjust the civil use or industrial application environment temperature and humidity: Temperature control, hHumidity control.
- ♦ Compressor control functiom: Compressor was is simple on and off load management.
- ♦ Ti ne setting function: Minimum running time, Mi imum closing time, in the same compressor
 o erate the minimal inter /al time and operate power control the shortes: delay time.
- Compressor alarm function: High prossure load alarm, low pressure alorm compression overload alarm, General alarm.
- Control one or two electric heating equipments, at most to three electric heating polyer energy le /els.
- ♦ T ie bulit-in electrode typ ; humidifying equipment.
- Equipment manual control function: Equipment can be manually controlled, and not affect by the tioning and sensor values. Under manual control state, it only responds the safety alarm. Manual control only is effective under power off. Under manual control, it can not be started.
- ♦ Temperature control of air-return port.
- ♦ Alarm management, Alar n record fu iction.
- Power-off memory: Sudd anly power off, the syst and has a memory function, the system automatically recover the operation state before power-off.

5. Operation

5.1 Temp erature/humidity set point setting fun ation

Press **Set** in menu, directly enter the user without password, and can change temperature and humidity setting point (*S1*).



5.2 Quer ' function for key componen is operating status

Press the **Statu** button, directly enter wi hout password. Enter to the interface, use **Up** and **Down** button; to turn over pages for query. Contents can be checked as following:

Analog inputs IO	Analog inputs I1
Amb-humidity 53%	Amb-humidity 28.2°C
Pr 1 19.1bar -32.2°C	Supply air°C
Pr 2 bar °C	External temp°C
Analog inputs I2	Dig.inputs1-3 I3
Recovery°C	Overl.or HP_C1 -C-
Temp.cond.1°C	Overl.or HP_C2 -C-
Temp.cond.2°C	Overl.Heat.1 -C-
Dig.inputs4-6 I4 Overl.Heat 2 -C- Power Status -C- Overl.Fan -C-	Dig.inputs7-8 I5 Air flow -C- Remote on/off -C-
Dig.inputs 9-11 I6	Dig.inputs 12-14 I7
Low press.C1 -C-	Fire/Smoke -C-

Analog outputsI9Cond.fan 1VCond.fan 2V	Analog outputsIaHumidiñerVMain fanVRecoveryV
Dig.outputs 1-3IbMain fanOffCompressor 1OffCompressor 2	Dig.outputs 4-6IcHeater 1OffHeater 2OffDehumidif.Off
Dig.outputs 7-8 Id Recovery Off Alarm Off	Dig.outputs 9-11IeFan 1Fan 2HumidpowerOff
Dig.outputs 12-14 If Humid.Fill Off Humid.Drain Off Not Used D014	Current total Ig Steam flow 00.0 kg/h The current demand 000% Conduct. 000uS/cm
Nominal Values Ih Nominal Output 008.0 kg/h Nominal Current 008.7A Voltage 400V 3-Ph	CylinderIiStatusOffActionCyl.OffAmps000.0A
Cyl.1 Cont. Off Ij Cyl.1 Fill Off Cyl.1 Drain Off	

Note:

Interfac is of Ig, Ih, Ii and Ij displar the humidi ier operatin i status.

5.3 Setting function of using paramet rs

♦ Press the **Prg** button in lenu, it nee I password to enter:



Note:

User password is 0002.

Press enter button to enter the temperature and humidity set point for parameters setting and use Up and Down to adjust the parameters setting:

Temp. Setpoint LimitP1Min.017.0°CMax.040.0°C	Humidity Setpoint Limit P2 Min. 000.0% Max. 100.0%
TemperatureP3Cool Tolerance003.0°CHeat Tolerance003.0°CNeutral Zone01.0°C	HumidityP4Dehumid Tolerance05.0%Humidity Tolerance05.0%Humidity Tolerance100.0%
P5 Show language mask at start-up NO Off unit by key YES En.remote On/Off YES	Temperature alram thresholds P8 Low offset 008.0°C High offset 012.0°C
Humidity alram thresholds P9 Low offset 020.0% High offset 035.0%	Sel. type alarm Pb S=serious N=not ser. A01:NNNNN A06:NNNNN A11:NNNNN A16:NNNNN
Sel. type alarm Pc S=setious N=not ser. A21:NNNNN A26:NNNNN A31:NNNNN A36:NNNNN	Sel. type alarm Pd S=serious N=not ser. A41:NNNNN A46:NNNNN A51:NNNNN A56:NNNNN

Sel. type alarm Pe S=serious N=not ser. A61:NNNNN A66:NNNNN A71:NNNNN A76:NNNNN	Identific. numberPffor BMS Network: 001001Comm.speed: 19200bpsProtocol type: Modbus
Pi	Setting Dehumi. Heater Pj
Change Password:	Setting Temp. 16.0°C
0002	Setting Tolerance 03.0°C

Notes:

Interface *P1* to set the temperature setting range. Interface *P2*, *P3* and *P4* to set the deviation and dea | zone. Interface *P5* for some special functions activation. Interface *P8*, *P9* to set temperature and humidity ala m. Interface from *Pb* to *Pj* for | larm selection.

5.4 Maintenance management

Press the laintenance button, and enter the following interface.

♦ C teck the software version and systom information:



♦ Operating time of hardware devices:



System Inform	nation A1
Midea	08/06/12
Bios 04.02	15/11/06
Boot 04.03	03/07/06



C teck the history alarm records and change device operating time:
 It must through interface *A5* enter to *A6*. After enter into the interface, it can directly from interface *A4* to *A6*.



Notes:

Please contact manufactur) for maintenance password.

K ep pressing **Down** button, the dis play screen will pop up Type in maintenance password. By U) button to type in password, an I then do the calibration setting of relative parameters in system.

Probe calibration: \diamond

Modify runn. hours An main fan 00.001h Humidifier hours reset No	Threshold runningA7hours alarm (x1000h)Main fan99Humidifcomp299
Probes settingA8Humidity0.0%Pressure 10.0barPressure 20.0bar	Probes settingA9Ambient temp.00.0 °CExternal temp.00.0 °CSupply air00.0 °C

C lange the maintenance password: ∻

Am
New maintenance Password: ****

5.5 Clock management

Press Clock button, and enter to the following interface, and change the system time of the controller:

Regulation clock	Ko
Hour	17: 55
Date	28/08/12
Day	Tuesday

Press **Down** button, enter to **(1** interface and type in clock management password **002**. Press **enter** to enter *K2* interface, then can use the relative functions of time zone control. In *K2* interface there only the corresponding control function selected **Yes** then can do the follow up detailed setting.



If it is not need the unit to be perated in some periods of a day, and want to close the unit to save energy, then it can set (interface K3, K4) to carry out timer on and off the unit, and it als) can set 7 days in a week to be different time zone for controlling (interface K5), which can realize not control by manual every day. Interface **a** to change the clock password.

On-off timezones K3 ON OFF F1-1 09:00 13:00 F1-1 14:00 21:00	On-off timezones K4 F2 ON 14:00 OFF 21:00 F3 \rightarrow Always ON F4 \rightarrow Always OFF
On-off timezones K5 Mon:F3 Tue: F3 Wed:F3 Thu: F3 Fri:F3 Sat:F3 Sun:F3	Temp. setpoint K6 ON SET Z1: 00:00 022.0℃ Z2: 00:00 000.0℃
Temp. setpoint K7 ON SET Z3: 08:00 024.0 °C Z4: 00:00 000.0 °C	Humidity setpoint K8 ON SET Z1 : 00:00 055.0% Z2 : 00:00 000.0%
Humidity setpoint K9 ON SET Z3: 08:00 050.0%	Ka New clock password 0002

6. Network function introduction

Manual operator and controle can be connected together by RS485 network, to make up the LAN, and realize the data and infor nation communication and group control functions. The manual operator can only display information of one controller in once.

The manual operator was used in the basic paramter setting, if one or more manual operators be disconnected or broken down, and then each controller will keep normal operation, no influence from the manual operator.

Group control network maximal connect 32 devicesw (terminal), and these devices include controllers and manual operators. Each device has the only iden ified address, the address range is 1~32. Address 32 is only assigned to ghe manual operator, and the controller address must be set to 1, then the main unit can only group control the units with the controller address 2~8, and the units with the address 9~31 will not control by the main unit, and keep their single operation state. Units named from 1 to 31 can accept the control of the share manual operator.



A controller can maximal manages 3 manual operators at the same time, but can not minage two kinds of manual operator at the same time. Three manual operators can update the information of their corresponding controller synchronously, and the corresponding relation:

- 1. Special (*Pr*), only display the output of this controller.
- 2. Share (Sh), can shift mor : than one controllers by pressing the Query button.

As the following picture show i, one share manual operator linked with three controllers, and only controller 1 can update the display date of the share manual operator and accept input command of manual operator, meanwhile, the other two controllers will continue to update the displar data of the special manual operator. To press the Query button of the share manual operator for circulated shifting (U:01>U:02>U:03>U: (1...). When address 2 and address 3 controllers have alarm information, their special manual operator will produce the alarm information, and at the same time also can control the share manual operator and produce alarm information.


6.1 Grou) control network setting

According to the previous picture, an example of how to set group control network will be given.

 \diamond Set the manual operator address of the device 2 to be 0.

Power on the controller, and wait the controller finish operation. Press **Up**, **Down** and **enter** buttons at the same time for 5 seconds to enter the configuration mode, the manual operator display as follow:

Display address	
setting32	
I/O Board address : 02	

Press **inter** button to move the cursor to the **32** field, and press Jp key to change the manual operator address to be **00**.

Display address setting00

Press *inter* button to confirm the manual operator address changing.



♦ Change the controller address of the device 2.

Cut off the controller power and the connections bet een J11 pot on the controller and other controllers.

Press **Jp** and **alarm** buttons it the same time, and power on the controller, until the screen display the following interface then stop pressing.

#######################################
selftest
please wait
#######################################

The manual operator will automatically shift to the following display, press **Up** button to set the controller address to be **2**, an I press **ent :r** for confir nation.

pLan address: 2
UP : increase
DOWN : decrease
ENTER : save & exit

 \diamond Set the manual operator address of the device 2 to be 31.

Press **Jp**, **Down** and **enter** bottons at the same time for at least 5 seconds to enter the configuration mode, the manual operator display as following:

ſ	
l	Display address
	setting00
Ļ	

Press **inter** to move the cuso⁺ to the **00** field, and priss **Down** to change the manual operator address to be **31**.

Display address setting31
I/O Board address :

Press **inter** to confirm the manual operator address changing.



♦ Configure the corresponding relation of controller and the manual operator.

Press **Jp**, **Down** and **enter** b ittons at the same time for at least 5 seconds to enter the configuration mode, the manual operator display as following:



Press **inter** button 3 times, the screen di iplay as following.



Press **inter** to enter the configuring page for corresponding relation of controller and minual operator, press **Up** and **Down** to select the manual operator address and the corresponding relation of manual operator and controller. Use **enter** button to confirm the setting and move the cursor, the manual operator display as following.

P:02 Adr	Priv/Shared
Trm1: 31	Pr
Trm2: 32	Sh
Trm3:	None OK? No

Notes:

P: 02 means that controller address is 02.

- Trm1: 31 Pr means that ma ual operato · 1 address i ; 31, the corresponding relation of manual operater 1 and contoller 02 is special.
- Trm2: 32 Sh means manual operator 2 address is 32, the corresponding relation of manual operator 2 and controller 02 is share.

Trm3: None --- means oper itor 3 address is empty.

So the controller with the address 02, it is special manual operator address is 31, and the share manual operator address is 3 !.

After setting, press enter to move the cursor to the No field, and change to be Yes by Down button,

and then press enter for confirmation, then finish group control network configuration of one device.

Set the manual operator and controller addresses of device 3 and set their corresponding relation.
 Repeat same steps for device 3, and set the manual operator and controller addresses. Set the corresponding relation as the following display:

Display address	P:03 Adr Priv/Shared
setting 30	Trm1: 30 Pr
setting	Trm2: 32 Sh
I/O Board address : 03	Trm3: None OK? No

Operations of the manual operator (Address No.32) /hich connected with device 1, configure the grop control function.

Press **Program** and **menu** buttons together to enter the factory password page. Press **enter** to move the cursor to the **0000** field, and type in pressword by **Up** button. Press **enter** to confirm entering factory configuration.



Notes:

Contact manufacture to get the factory password details.

Press **inter** to enter the interface of configuration management.

Configuration	
Parameters	
Carel EXV Drivers	
Timing	

Find the **Co** page by pressing **Down** button, and press **enter** to confirm the setting. Move the cursor, select the relative parameters by **Down** button.



Press **nenu** to exit the interface of configuration management, and press **Down** to move the cursor to the interface of parameter nanagement, then press **enter** to confirm entering, and then find interface Gm by **Down** button.



Then the units operate after setting, there are several functions:

1. Conflict management

Manage by the main unit, and carry out cooling, heating, huidification and dihumidification, avoid to competed operations.

2. Main unit and backup unit shifting

W len there are errors in the units of the group, the backup units will automatically operate, to increase the reliability of the aire conditioning system.

3. Rotation type

Automatic rotation: The current rotation time set t $rac{1}{2}$ be **0** hour, is used to test the rotation condition, every 5 minuts will carry out one rotation. The current rotation time set to be none 0 hour, the carry out result is the same as running hours.

Running hours: Ratation as hours ($000 \sim 240$ h), e 'ery 24 hours will carry out one rotation, under this rotation type, it can not set the rotation time to be **0**.

Ti nezones: Rotation as tilne zones, carry out on rotation as the setting hour 22:00 of every Wildnesday, and set other two rotation type the **i0** interface will be displayed, and select other two rotation types the **G0** interface will not be displayed.

4. Load adjustment

The absolute value of difference between ambient temperature and setting temperature is higher than 8°C, then it will operate standby after 3 minutes.

The absolute value of difference between ambient temperature and setting temperature is lower than 4°C, and then it will close standby.

♦ Wire figure of controller in group control network.

3-core shielding wire (large or equal to 0. 75mm²) is used to connect the controller and the J11 port, which has polarity. It needs to correctly connect Rx-/ x-, Rx+/Tx+ and GND. The maximum distance of the controller wires should be 500 metors.



- ✤ Functional verification for group control network.
 - ✓ B :fore verifying the grou → control network funciton, it needs to confirm all the networking units ar ∋ noumal when it is operating by single (without shutting down for error).
 - ✓ After configure all the addresses of anual operator and controller in the group control network and their corresponding relations, successively operate main power, controller power and indoor power for every units.
 - ✓ After the controller operation, press lown, Up and enter keys at the same time for at least 10 seconds, then can check the online status of connect devices in the group controller network.



✓ On the manual operator vith address No. 32, press Query to check the U:01 on the MO interface whether shift to differents units as : :01>U:02> J:03>U:01 ...

10:25	20/12/10	MO
Temperature	020. 0°C	
Humidity	050.0%	
Keyboard close up		U:01

- Press on/off to operate all the units in the network, to check whether the units are under standby status. Press on/off to close one of the operated units to check the under standby units whether it vill automatically turn to ben on status. And then re-operate the unit just closed to check whether the standby units will back to standby status.
- E iter the *Gn* interface, c loose the rotation type to *Automaticn Rotation*, the standby quantity to be *1*, and rotation time set to be *0*. Check whether the units are under standby status, and whether carry out a rotation every 5 minutes.
- Press set to enter temperature/humi lity setting interface S1, set the setting temperature to lower than the ambient temperature 10°C, hen after 3 minutes to sheck the under standby units whether will automatically turn to be on status. And then set the setting temperature to be the same as the ambient temperature to sheck whether the standby units will back to standby status.
- ✓ S st the parameters of *Gn* interface and *S1* interface to be the values required by the actual operations.

- ♦ Cancel group control network.
 - Close the unit. Switch off the controller power and the network connections of controller J11 port and other controllers.
 - ✓ Change the corresponding manual o perator address of devi ≥ 2 and device to be 32, controller addresses to be 01, and configure their corresponding relation as following:

Display address	P:01 Adr Priv/Shared
setting32	Trm1: None
I/O Board address: 01	Trm2: 32 Sh Trm3: None OK? No

✓ Change device 1 to C0 interface and Gm interfa :e as following:

Units configurat. Co	Master control	Gm
U1: Present/No Rotat.U2: Not presentU3: Not present	enable	No

6.2 The ethernet communic tion card introduction

♦ TCP/I ' communication card (Ethernet communication card)



- ✓ This card can provide net work connector, and also can view the data through the Internet Eplorer. The air conditioner is directly connected with the computer by the ether let communication card.
- The network diagram of t ieTCP/IP communication card (Ethernet communication card) by S IMP protocol is shown as following picture, and the connecting quantity of air conditioners are no restriction.



- ✓ In stallation of the ethernet communication
 - 1. The board of TCP/IP card is installed in the pCO* controller.
 - 2. Switch off the main power. Remove the cover of card from the pCO* by a screwdriver.



3. Insert the TCP/IP card in th corresponding plug-in connector, making sure it is sully inserted and in contact with the two supports located on the case of the pCO*. This operation may be difficult due to the limited space, consequently, it is recommended to insert the locard at an angle and then turn it until aligning the connectors.



4. Clos the cover again, using the cover supplied with the board of TC ³/IP card, li ing up the connector on the serial board with the opening in the coner.



- 5. Stick one or both label, so that the MAC address can be read witho it needing to open the electrical panel.
- 6. For the connection to the ethernet network, use an S/FT² cable, category 5e or higher.
- ♦ RS485 communication card



- ✓ RS485 communication card is as shown in follo ring picture. The RS485 card also an provide network connector, and also can vie r the data through the Internet Explorer by connecting R232/R485 converter.
- ✓ The network diagram of US485 cominunication and is as shown in following picture. It can connect maximum 200 sets air conditioners, and the longest R485 connecting wire which use

shielding cable is 1000m.



- ✓ Installation of RS485 car I
 - 1. Remove the serial card placement cover with a screwdrive.



2. Remove the pre-pun stured plastic, the hole which corresponds to the tree-pole terminal out will be found.



3. Insert the optional card into the corresponding connector, taking care that the card is firmly placed on bothe plastic supports on the pCO case.



4. Close the cover using the screwdriver makin; the outside card terminal fits with the punched hole made on the cover.



5. The connection with the RS485 network is carried out by means of the plug-in terminal

connector on the card.

6. There is a table of Pin-wiring of the connector stamped on the card.

Pin	Significato meaning
1	GND
2	RX+/TX+
3	RX-/TX-

7. Maintenance

7.1 Electrical maintenance

According to the following items to check appearance of the electrical connections and do the relative handlings. Before fastening any assembly connections and circuit connections, it must ensure that the power supply of the control element has been closed.

- ♦ The electrical insulation test: find out the unqualified contacts and handle them. During the rest process, pay attention to disconnect the control part of the safety or air switch, to avoid high voltage damaging the control panel.
- ♦ Static detect the suction port of each contactor is flexible or not, and whether there is card resistance.
- ♦ Use a hairbrush or dry compressed air to clean dust for the electrical and control components.
- Check the suction port of the contactor whether has arc discharge and burn mark phenomenon.
 When it is serious change the corresponding contactor.
- ♦ Tighten each electrical connecting terminal.
- ♦ Check whether the plug-in quick connectors whether contact well, if there is any loose condition it should be replace the terminal.

7.2 Control maintenance

According to the following items to do the appearance check, simple function test of the electrical connections and do the relative handlings. Before fastening any assembly connections and circuit connections, it must ensure that the power supply of the control element has been closed.

- ♦ Check the appearance of the power transformer and isolated transformer, and detect the output voltage of indoor unit and outdoor unit.
- ♦ Detect the surfaces of control connector panel, display panel, sensor panel and safety panel whether there has obvious ageing.
- ♦ Clean the dust, dirt on the electric control elements and control panel by hairbrush with the electronic cleaning agent.
- Check and tighten control each input and output plug-in connector of the control connector panel, including the connection of display panel and control connector panel as well as the connection of the control connector panel and temperature/humidity sensor panel.
- ♦ Check the connection of the wiring terminals (J10, 01/45, 01/47, 01/48, etc.) and controller connector panel.

- C teck the output connection between the control connector panel to e ich contactor, liquid pipe electromagnetic valve, and the input connection between the control connector panel to fan overload protection devixe, high/low pressure switch, heating thermal protection switch, filter screen clogging switch and air flow switch. It is sould be focusing on checking the terminals of high/low pressure switch and electromagnetic valve, if there appear loose, poor contacting conditions then it should be replaced immediately. Replace the control fuse (or air switch), control panel, electric components which have existing problems.
- ♦ C teck the control wiring between the indoor unit and condenser or the specification of power wire and the ageing situation, when tecessary, replace the wires.
- ♦ Use temperature and hu nidity measuring instrument with higher measuring precision to check, calibrate the reading of the temperature and humidity sensor. During the calibration of the humidity sensor, pay attention to select the humidity control way to be relative humidity control.
- \diamond C teck the external sensors:
 - Fireworks detector (If installed)
 Fireworks detector is located on the wind power base panel of the upper air out unit and the top of the lower air out unit. It continually loes the analysis judgment through collect the return air sample, an I it does not need to adjust.
 - 2. Water leakage detecting sensor Water leakage detecting sensor contains a pair of dry contact switch, and when a pair probe of the switch detect the water (or other conductive liquid), this switch is closed immediately. The sensor should be placed far away from the wet tray or floor dewatering places, and from the unit about 2 to 2. I meters. It shall not directly install under the unit.

7.3 Filter screen maintenance

To ensure the reliable operation, the filter screen must be monthly check and change as requirement. The position of filter screen clogging switch and air flow switch. The display positions in the following igure are for reference only, due to the different model, and the specific lobations may be different.



S iut off the power before changing the filter screen. If change the same type of filter screen, it do not need to reset the filter screen cl gging switch, otherwise, it needs to calibrate the setting of the filter screen clogging switch. The filter screen clogging switch is located in the electric control box, and collect the large air pressure and filtered air pressure through the white soft hose, and the filter screen clogging switch to compare the two pressure difference to judge the output.

- When installs different type of filter screen, in order to accurately find emergency alarm, it must install all the panel of the device in places and keep closed. Under the fan is operating, as the anti-clockwise direction to rotate the setting knob of the filter screen clogging switch, to make the switch contact the filter alarm, and then as clockwise direction to rotate the 100Pa deviation pressure, and then install the plastic protective cover of the filter screen clogging switch in place.
- Notes:
 - 1. Setting point shall be appropriately, and can not deviate too much, or it will due to dirty filter screen and cannot trigger the alarm, and then cause the small system air volume and lead to abnormal operation of the system.
 - 2. To change different type of the filter screen and adjust the setting, it should be confirmed by manufacture.

7.4 Indoor fan components maintenance

Periodically check the fan components, including: belt, motor frame, fan bearing and impeller. The motor and installation panel are integration design and use bolts to fix on the installation panel. After a period of using, it should be check whether the bolts are loosened. If they are loosened, they should be promptly tightened.

♦ Fan bearing and impeller

It should be regularly check whether the fan and fan spindle are installed firmly or not. Turn the fan impeller to make sure it cannot clash the scroll shell. Use the bearing of this component is permanently sealed and self-help lubricated. During regulating the belt, it should be examined for the attrition phenomenon. Turn the belt pulley to check the rotating condition of the fan spindle. If it was found to have any big movement, then needs to replace the bearing.

 \diamond Belt

> Use the belt tension meter to detect the tightness of the belt. Or in the connection center of motor wheel and fan wheel to tight the belt, it should has 1/2'~1' displacement. If the belt is in damage or deformation status, use the same type of belt for replacement.

 \diamond Motor

> When the motor appears abnormal sound, burned etc, factors to make invalidation, needs to be changed, for upper air supply unit. It should pay special attention for safety. It must use special tools to hold the motor and then dismantle fixed the bolt of motor base.

7.5 Humidifier maintenance

During the normal operation of the humidifier, articles such as mineral salt will gradually deposit and form scales on the internal wall of the humidifier tank. These scales must be regularly cleared, which can guarantee the efficient operation of humidifier. Because of different water gualities, the cleaning time should be based on the local specific situations. It is suggested to check monthly.

- \diamond Please do not use cleaning agent and solvents to clean the plastic components.
- ♦ Use materials which contain 20% acetic acid to remove the scales and residue in the water.

♦ Instruction of the steam humidifier component parts which need to maintain.



Item	Na ie
1	Support frame
2	Water supply tank + Conductivity meter
3	Water i ilet flexible pipe of humidification tank
4	Water i ilet solenoi I valve (24 'AC)
5	Gasket
6	Straight-water drai lage conne :tor
7	Humidification locking belt
8	Overflo v pipe
9	Water i ilet flexible pipe of wat ir supply taik
10	Water supply connector (Connect to humidification tank.)
11	90° angle water drainage bend
12	Water drainage solenoid valve (24V AC)

- ♦ Maintenance methods
 - 1. Humidification tank hay be hot, so firstly cool the humidification tank or use protection gloves before operation.
 - 2. After broke off the connection of the cable and pipes, dismantling the electromagnetic valve, and check the status of the inlet filter. Check whether it is necessary to use water and soft brush for cleaning the filter.
 - 3. Check whether ther are solid adhesives in the humidification tank, and remove the impurities. Check the seal O-shape ring whether has been damaged or broken, if it has any damage or broken, replace it.
 - 4. Disconnect the power supply, an | take down all the sensors, then unscrew the bolt and valve body, to remove all the impurities and clean it.
 - 5. Check the water supply tank whether has an *r* obstacles or solid particles. Chec t whether the conductivity probe is clean or not, and remove all the impurities and clean it.
 - 6. Check these pipelines whether it was cleared and no impurities. If it has any impurities,

remove all the impurities and rinse off.

- ♦ Disassembling the humidification tank
 - 1. Press the Manual dr inage button to empty the water in humidifica ion tank.
 - 2. Close the unit, and s *r*itch off the power supple for safety operation. Open and take down the cap.
 - 3. Take down the steam pipe from top of the humidification tank.
 - 4. Break off the electrical wirings from the top of the humidification tank.
 - 5. Loosen the fastening devices of jumidification tank, the i lift it and take it down.
 - 6. According to the reverse order of above steps to install a new humidification tank on the humidification.
- ♦ Clean the humidification tank
 - 1. Take down the humidification tank, and use pross-screwdriver to screw open the connecting screws of the clamp in the middle of humidification tank.
 - 2. Take off the fixed clamp, and vertically take out the humidification tank core body from the humidification tank.
 - 3. Place the humidification tank co e body into acetum with 20% density, waiting for scale to loose, and wash awa *i* all the scales carefull by a soft hairbrush.
 - 4. After cleaning, install the humidification tank core back to the humidification tank, and fasten the connecting clamp.



7.6 Electrical heating components

Check the rust situation of electrical heating components, and use iron brush for de-rusting, or according to the situation for replacement. The internal circuit of the electric heating internal combination has tandem conject two temperatures vitches. When there is neating demand but has no heating effect, then it should check whether the temperature switches have been reset.

7.7 Refri |eration system

It must monthly check the components of the refrigeration system, to view whether the system function is normal and has any sign of wear or not. For it was often accompanied by the corresconding errors before the components fail or devices damage, so regular inspection is the main neasure to prevent most system failures. Refrigerant pipe must have the suitable bracket, and should not rely on the ceiling, floor and fixed frame vibration place. Check the refrigerants pipeline every six months, make sure whether the / were worn or the existed fixing structure has loosen or not. Each system is equipped with a liquid sight glass for observing liquid refrigerant flow and water

situation of the system. When the water content of system is more than the standard, the liquid sight glass basic color will change from green to yellow. When the refrigeration system has malfunction, judge the error according to some operating parameters of the system.

- When the suction pressure drops to below the set value of low pressure switch, it could lead to the compressor stops. On the other aspect, high suction pressure also can be reduced to cool the compressor motor, which may cause compressor damage.
- Discharge pressure may be increased or decreased for the load conditions or the efficiency of the condenser. When the discharge pressure reaches the setting value of the low pressure switch, the high voltage switch action will make the compressor stop.
- Thermal expansion valve can adjust the suction overheat degree. The suction overheat degree has great influence for the using life of compressor, if the compressor operates on the situations of too small or no suction overheat degree for long time, it may be directly led to compressor produced liquid strike, which will crush the scroll compressor. Follow the below operations to confirm the suction overheat degree of system:
 - 1. Measure the suction wall temperature in the thermal expansion valve temperature sensing position.
 - 2. Take the compressor suction pressure sample from the needle valve of suction pipe.
 - 3. Estimate the pressure difference between the temperature sensing position and the needle valve of suction pipe.
 - 4. The sum total of above two pressure plus one local standard atmospheric pressure value, then find out the corresponding saturated temperature of the saturation pressure.
 - 5. The suction overheat degree is the difference of the suction temperature and this saturated temperature.

7.8 Compressor monitoring and replacement

This precision air conditioning system uses high efficient scroll compressor, which has high reliability. If the project construction strictly accord with the correct program operations, then the probability of failure which appears in operation process is very small.

If the problems which may result in compressor error can be early detected and corrected, then most of the compressor errors can be avoided. So it is suggested that customer should regularly contact the service of manufacture to do compressor operation state test, and do the monitoring records.

During the compressor monitoring, check whether all electrical components of compressor are running normally.

- 1. Check whether the corresponding air switches and contactor of the compressor are sensitive and normal.
- 2. Check whether the high and low pressure switches are sensitive and normal.
- 3. Check whether the upper discharge temperature switch of the compressor has been fixed reliably and done the thermal insulation.
- 4. Check whether the compressor wiring terminals resistance value is normal and the grounding insulation is normal.
- If for neglecting the inspection or other reasons to cause the compressor error, then before changing the compressor it must be carefully do the fault analysis, the common errors mainly to be the following two aspect:

1. Mechanical error

The mechanical error of compressor is mostly because that during the installation process it is not strictly accorded to the operation guidelines, and the system refrigerant leakage and improper trial run in the process of the construction and operation, and then cause the compressor return liquid operation in long term.

Under such cases can lead to the compressor internal temperature over high, and mechanical error including in the scroll badly worn, scroll jammed, and so on. For external performance, the motor inside compressor resistance may be normal, but large noise will be produced after the compressor start. When the error compressor starts, the pressure difference between compressor suction and discharge ports is zero. If it is confirmed that there are mechanical errors, then it must to replace the compressor.

2. Electrical error

The compressor electrical error mainly is that the compressor was burned and the wiring terminals are blew out. Under this case, after power on the compressor, compressor still is without any response. At this time, it should cut off the electricity, and then open the compressor wiring box for visual inspection or using a multimeter to check the compressor resistance. If there is any electrical error, it is necessary to change the compressor.

- When compressor happens to completed burned, replace compressor and it also should be replace drier-filter, and check the expansion valve. If there is any error, it also should be replaced. Before the replacement, clean the system is necessary by right method. When changing the compressor the skin must be avoided to directly contact with the refrigerant or lubricating oil, otherwise it will cause severe frostbiting the skin, and it must wear protective gloves for handling the contaminated components. After replace the compressor it must do serious analysis and exclusion of the compressor error reasons, otherwise it may lead the new compressor to be burned again.
 - 1. Cut off the power supply.
 - 2. Separate insert the suction pipe needle valve and discharge needle valve on the low pressure and high pressure connectors of the pressure gauge, and to release the refrigerant.
 - 3. Disconnect the electrical connection of the compressor.
 - 4. Loosen the threading connectors in the suction pipe and discharge pipe of the compressor.
 - 5. Remove the error compressor.
 - 6. If the compressor was completely burned, it should clean the refrigeration system pipelines, and replace the drier-filter and liquid sight glass.
 - 7. Install the new compressor in place, and connect the pipeline connectors and electrical circuit well.
 - 8. According to the requirements of the debugging to vacuum the system and add refrigerant.
 - 9. As the normal trial run to power on the system, check whether the system operation parameters are normal. Through the liquid sight glass to observe the refrigerant status, and combining with the system pressure and temperature parameters to confirm the adding amount of refrigerant, until the system runs normally.

7.9 Outdoor fan maintenance

Check whether the fan operates normally, noisily, vibrates or blocks the bearing, etc.

8. Trouble shooting

When the system is suddenly having a demand, but there is a failure or invalidation which led to non-workable, and then it cannot meet environmental needs. So it is necessary to periodically do the functional test for the system components. Controller provides field manual opening and closing function for all parts, and use for self-detecting the functional components' states of the system. Detailed operations can be checked by system self-diagnostic function.

During the device operation, the internal unit may have a deadly high voltage. It only allow specialized technical person to do the unit maintenance operation, and must be especially careful during the troubleshooting with electricity.

5	
Probable reason	Check items or handling methods
No main power supply	Check the voltage between A, B, C.
Overload, air switch is broken off	Manual reset, check the average current value.
	Check whether has 24V AC voltage between 28
Contactor cannot contact together	and 03. (Wire numbers) If it has, then the
	contactor has error, change it.
Control panel error	Check whether has 24V AC voltage between 28
	and 03. If not, the control panel has error.
Air flow lost switch alarm (activate)	Check whether the belt has loosened or fan motor
	has error, if not, then check whether the air flow
	collecting plastic pip has abnormal position.
Fan error.	Replace it.
	Probable reason No main power supply Overload, air switch is broken off Contactor cannot contact together Control panel error Air flow lost switch alarm (activate) Fan error.

♦ Common faults and handling methods of indoor fan

♦ Common faults and handling methods of dehumidification system

Symptom	Probable reason	Check items or handling methods
	System does not require carrying out dehumidification.	Check the control system status.
	Contactor of compressor cannot contact together.	Refers to refrigerant system
		handling methods.
No dehumidification effect	Compressor does not operate, the air switch broke off.	Check the air switch, contacting
		points, check the air switch
		voltage.
		1, Check whether has 24V
	Dehumidification solenoid valve error	voltage between wire 33 and wire
		03.
		2, Check whether reliable installs
		the wires and valves.

♦ Common faults and handling methods of humidification system

Symptom	Probable reason	Check items or handling methods
	No water filling in the humidification tank or low filling water pressure.	Check the water source.
		Check the water inlet solenoid valve is open.
No		Check whether the water inlet pipe has blocked.
humidification	No humidification requirement.	Check manual operator.
effect No 24V AC input at controlling humidification contactor.	No 24)/ AC input at controlling airs aids of	Controller error.
	humidification contactor	Wiring from controller to the humidification
		contactor controlling wire port is loose.

♦ Common faults and handling methods of heating system

Symptom	Probable reason	Check items or handling methods
Heating system does not operates	No heating requirement.	Check the controller status.
neating system does not operates,	Heating temperature controller is	1. Wait for the controller reset.
contactor do not contact together.	broken off and not reset.	2. Change a new controller.
The contactor contacted together,	Heater arren	Turn off the power, check the
but no heating effect.		heating pipe and wire.

♦ Common faults and handling methods of refrigeration system

Symptom	Probable reason	Check items or handling methods
	Power off (Off the unit)	Check the main power switch, fuse and
		connecting wires.
	Power overload and the air switch broke off.	Manual reset, check the current and air switch.
Compressor	Electrical circuit connection is loose.	Fasten the connection.
cannot run.	Compressor wire circuit has burnt.	Check the compressor terminal.
	The built-in protector of compressor has	Check whether the compressor wire circuit is
		open. If open, cool down the protector, then
	bloken on.	automatically reset.

Symptom	Probable reason	Check items or handling methods
	Power off. (Off the unit.)	Check the main power switch, fuse and
		connecting wires.
	Power overload and the air switch broke off.	Manual reset, check the current and air switch.
	Electrical circuit connection is loose.	Fasten the connection.
	Compressor wire circuit has burnt.	Check the compressor terminal.
Compressor cannot run.	The built-in protector of compressor has broken off.	Check whether the compressor wire circuit is
		open. If open, cool down the protector, then
		automatically reset.
	The contactor cannot contact together. No	Check the manual operator parameters setting
	24V voltage input for the compressor control	correct or not. Check whether the controller is
	wires. Or not reach the operating conditions	error, or wiring from controller to compressor
	of compressor.	port is loose.

Symptom	Probable reason	Check items or handling methods
Air suction and	Reverse the compressor or inner air	When the compressor was reversed, change
exhausting pressure	mixed up.	any two L wires. Inner air mixed up, change
have no difference		the compressor, Check the leakage and
after operation.		maintain, and add refrigerant, change the
		drier-filter.

Symptom	Probable reason	Check items or handling methods
High air exhausting	Refrigerant leakage.	Check whether the leakage and maintain, and
temperature		add refrigerant.

Symptom	Probable reason	Check items or handling methods
	Condenser has been blocked.	Clean the condenser.
	Condenser fan cannot run.	1, Check the wiring was correct or not.
High air exhausting pressure		2, Check whether it has 3~10V DC between
		wire 22 and wire 05. If has, the outdoor
		inverter is error. And if no, check the indoor
		unit controller.
	Too much refrigerant adding amount.	Fasten the connection.

Symptom	Probable reason	Check items or handling methods
	Look of refrigerent in eveter	Check the leakage and maintain, add
	Lack of reingerant in system.	refrigerant.
	Air filter too dirty	Change the air filter.
	Drier-filter is blocked.	Change the drier-filter.
Low air	Non-correct overheat adjustment	Strictly accord to the adjustment steps to
suction		adjust the thermal expansion valve.
pressure or		1, Check the temperature sensor and the
return liquid.	Expansion valve error	balance pipe whether have leakage.
		2, Check the expansion valve whether has
		serious frosting.
	Condensed pressure too low	Check the fan operates normally or not.
	Belt creep	Check the belt and adjust it.

Symptom	Probable reason	Check items or handling methods
	Poturo liquid	Refers to Low air suction pressure or return
Large	Return liquid.	liquid.
compressor	Lubricating oil lost and cause bearing	Add the lubricating oil.
noise.	damaged.	
	Compressor or pipe line is loose.	Fasten the connection.

Common faults and handling methods of outdoor fan system
 Both error and alarm are the abnormal working states of inverter. But there are different. Inverter will self-check during operation. If there is error, the inverter will display error code, and cut off

the inverter output to stop the motor and make it stay free running condition. If there is alarm, the inverter will display alarm code, and will not cut off the inverter output during alarm state, the motor still be controlled by the inverter.

Many methods of inverter error reset: Press the **Reset** button in keypad of inverter, reset function of terminals, or if necessary, power off the main power for a while then can reset the error. If error has been solved, the inverter will recover to normal operation. If error still not has been solved, the inverter will recover to normal operation.

The alarm reset of inverter only effect by operate the **Esc** button in keypad of inverter. When no display after power on:

- 1. Use the multimeter to check whether input power of inverter is same as the rated voltage.
- 2. Check whether the *Charge* lamp whether lights up.
- 3. If the above are normal, then maybe the power switch has error.

When the inverter does not run after the motor operation:

Cut off the connecting wire between inverter and motor, operate the inverter in 50Hz, and use multimeter to check whether there is equivalent AC between U, V and W. Use simulate voltage meter for measurement (the range is AC500V). If there is not equivalent voltage or no voltage, then the inverter had been damaged.

Notes:

Between U, V and W are high –frequency impulse.

Code	Туре	Error reason	Solutions
E001	Over current error, current is higher than 150% of Maximum current.	Speed up and down times too short.	Extend the speed up and down time.
		The inverter power is too small	Select a large power inverter.
		Voltage is too low.	Check the input voltage.
E002	Power module error	Speed up and down time is too short.	Extend the speed up and down time.
		The inverter output side is short circuit.	Check the insulation of motor.
		Power module is damaged	Replace the module.
		Outer disturb.	Find out disturb and eliminate it.
E003	Bus overvoltage error, the value is more than 570V.	Speed down time is too short, regenerated energy too large.	Extend the speed down time.
		Voltage is too high.	Check the input voltage.
		Load inertia is too large, regenerated energy too large.	Select a large power inverter.
E004	Bus voltage error, the value is less than 171V.	Voltage of power supply is too low.	Check the input voltage.
E005	Motor load error, the motor current is higher than standard inverter current.	Voltage is too low.	Check the input voltage.
		Load inertia is too large.	Check the load inertia, adjust torque lifting capacity.
		Not correct standard current setting of motor.	Reset the standard current of motor.

		The inverter power is too small.	Select a large power inverter.
E006	Inverter overheat error, the temperature is higher than 90°C.	Ambient temperature is too high.	Check the ambient temperature.
		Ventilation of inverter is not well.	Improve the ventilation environment.
		Cooling fan error.	Check the cooling fan work or not.
		Temperature detection circuit error.	Replace the detection.
E007	Soft start error	Soft start circuit or contactor is damage.	Replace soft start.
F000	Output with lack of phase	Current of 3-phase output side is	Check the output connecting wire and
E009	error	asymmetric	motor insulation.
E010	Out device error	Out error signal input terminal activates.	Check the outer error reason.
		The stop key is set to be emergency stop.	Check the stop key.
E012	Current detection circuit error	Current detecting components are damaged.	Replace the detection.
E013	EEprom read and write error	Control panel components of inverter are damaged.	Change the inverter
		Outer disturb.	Find out disturb and eliminate it.
E015	CPU disturb error	Outer disturb	Find out disturb and eliminate it.
E030	Error alarm	This is an alarm; the inverter output will not stop.	Press Esc key to exit the alarm status.

9. Accessories

Indoor unit

Name	Quantity	Shap e	
User's nanual of indoor unit	1		
Installation frame for water leakage sensor	1		
Switch anel component	1	E.	
Door ke /	1		(Placed on the door plate.)

Outdoor u it

Name	Quantity	Shap e	
User's nanual of outdoor unit	1		
Bottom components	4		For horizontal install
Screws components	24		For horizontal install

Annex I: Alarm table

Alarm display	Result	Probable reason
Low pressure compressor 1	Switch off the compressor 1.	10s after the low pressure switch is trigged.
Lose of airflow (Serious Alarm) UNIT OFF	Switch off the unit	10s after the airflow switch from close to open.
Main fan overload(Serious Alarm) UNIT OFF	Switch off the unit	Indoor fan motor protector acts.
EL heater1 overload	Switch off the E-heater 1	The overload protector of E-heat 1 acts.
EL heater2 overload	Switch off the E-heater 2	The overload protector of E-heat 1 acts.
Fire / Smoke detected(Serious Alarm) UNIT OFF	Switch off the unit	Fire/smoke protector acts.
Power alarm	Switch off the unit	Phase sequence protector is trigged.
High room temperature		It keeps 10s after difference between Ta and Ts is higher than design value. The unit will alarm.
Low room temperature		It keeps 10s after difference between Ta and Ts is lower than design value. The unit will alarm.
High room humidity		It keeps 10s after difference between Ha and Hs is higher than design value. The unit will alarm.
Low room humidity		It keeps 10s after difference between Ha and Hs is lower than design value. The unit will alarm.
Operating hour threshold reached for compressor 1		Only remind, need to cancel alarm.
Operating hour threshold reached for mail fan		Only remind, need to cancel alarm.
Room temperature probe faulty or disconnected	Switch off E-heater and compressor	 a、 When Ta is lower than -30°C and keeping 60s, alarms and switches off all the E-heater. When Ta is lower than 50°C, 999.9°C will be displayed. b、 When Ta is higher than 80°C and keeping 60s, alarm and switch off compressor. When Ta is higher than 95°C, 999.9°C will be displayed.
Supply temperature probe faulty or disconnected		 a When Ts is lower than -30°C and keeps 60s, unit will alarm. When Ts is lower than -50°C, -999.9°C will be displayed. b When the supply air temperature is higher than 80°C and keeps 60s, unit will alarm. When it is higher than 95°C, 999.9°C will be displayed.
Room humidity probe faulty or disconnected	Switch off humidifier and compressor	 a、 When Ha is lower than 5% and it keeps 60s, unit will alarm and switch off humidifier. b、 When Ha is higher than 90% and it keeps 60s, unit will alarm and switch off compressor.
Condenser 1 pressure probe faulty or disconnected	Switch off compressor	 a. When discharge pressure displayed is lower than -3.4bar and it keeps 60s, the unit will alarm. b. When discharge pressure displayed is higher than 37.4bar and it keeps 60s, unit will alarm.

Built-in humidifier: high current	Switch off humidifier	Actual current of humidifier is 130% higher than standard current for long time.
Built-in humidifier: no water in the cylinder(cylinder off)	Switch off humidifier	After water inlet valve is opened, actual current in humidification state cannot reach current of evaporating.
Built-in humidifier: low current	Switch off humidifier	Conductivity of water inside humidifier is lower than 75µS/cm.
High pressure compressor 1 thermal overload	Switch off compressor 1	Discharge pressure 1 is higher than top limit of pressure sensor.
High pressure + compressor 1 thermal overload	Switch off compressor 1	Pressure protection of compressor 1 is trigged.
Operating hour threshold reached for humidifier		Only remind, need to cancel alarm.
Clogged filter		When sensor of filter is trigged and it keeps 10s, unit alarms.
Water under floor(Serious Alarm)	Switch off unit	Water leakage sensor is trigged.
pLAN disconnected		 a. When unit from address U2 to U8 is disconnected from group and it keeps 60s, unit will alarms. b. Controller of pLAN address (except address 1/0) is disconnected with controller of address 1 and it keeps 60s, unit alarms.
Built-in humidifier: high conductivity alarm	Switch off humidifier	Conductivity of water inside humidifier is higher than 2000µS/cm.
Built-in humidifier: high conductivity pre-alarm		Conductivity of water inside humidifier is higher than 1500µS/cm.
Built-in humidifier: low steam production	Switch off humidifier	
Built-in humidifier: water drain alarm(cylinder off)	Switch off humidifier	After water outlet valve opened, operates with high current in humidification state.
Built-in humidifier: cylinder full alarm(cylinder off)	Switch off humidifier	Non-humidification, the sensor of water level is trigged.
Built-in humidifier: cylinder being depleted signal		Humidifier should be maintained.
Built-in humidifier: presence of foam		Foam produce because of alkalescency water inside humidifier.
Built-in humidifier: cylinder depleted		Humidifier should be maintained.
Built-in humidifier: compulsory maintenance alarm Cylinder 1		Humidifier already works for 10000h.
Built-in humidifier: recommended maintenance signal Cylinder 1		Humidifier already works for 2000h. It should be maintained.

Note:

Ambient temperature: Ta

Setting temperature: Ts

Ambient relative humidity: Ha

Setting relative humidity: Hs